
# 2-Color Display High Precision Digital Pressure Switch





The settings of the master pressure switch (source of copy) can be copied to the slave pressure switches.

Reduction in setting work
 Prevention of mistakes in setting




# **Easy handling!**



Raised rubber switch buttons for easy and comfortable operation

# 3-step setting



# **2**-color display

See abnormal values at a glance.














# **Piping Variations**


# Space-saving







# **Mounting Variations**







# **Series**



#### Secret code setting function .....

A function to prevent operation by anyone other than the designated operator while the keys are locked.



\* The set-value can be checked while the keys are locked.

# Power-saving function .....

The display can be turned off to save the power consumption. (Power consumption reduced by max. 20%)



The value disappears and decimal points start flashing

#### Resolution conversion function .....

The flickering on the display can be eliminated.



(Only the displayed value is changed, and there is no effect on the accuracy.)

## MPa/kPa switching function·····

The indication unit for vacuum, compound pressure and positive pressure can be integrated into either MPa or kPa.




kPa Stick the label (enclosed with the product) of a desired unit



# 2-Color Display High Precision **Digital Pressure Switch**





N01 (With M5 female thread) Rc1/8, G1/8 W1 Rc1/8 WF1\* G1/8 Rc1/8, G1/8 M5 x 0.8 M5\* (Female thread) M5 x 0.8 C4\* ø4 one-touch fitting C6\* ø6 one-touch fitting ø4, ø6 one-touch fitting

#### Combination of piping specifications with option 1 and part numbers of options

Optio	Piping								
Description	Symbol	Part no.	01	N01	W1	WF1	M5	C4	C6
Bracket A	Α	ZS-24-A	0	0	0	0	×	×	×
Bracket B	В	ZS-24-B	×	×	0	0	×	×	×
Bracket D	D	ZS-24-D	0	0	0	0	×	×	×
Daniel manual adapted	_	ZS-35-C	0	0	×	×	×	×	×
Panel mount adapter	E	ZS-35-D	×	×	0	0	0	0	0
Panel mount adapter +	F	ZS-35-F	0	0	×	×	×	×	×
Front protective cover		ZS-35-G	×	×	0	0	0	0	0

#### Output specifications

R	NPN open collector 2 outputs + Analog voltage/Auto-shift switching
Т	PNP open collector 2 outputs + Analog voltage/Auto-shift switching
S	NPN open collector 2 outputs + Analog current/Auto-shift switching
٧	PNP open collector 2 outputs + Analog current/Auto-shift switching
Х	NPN open collector 2 outputs + Copy function
Υ	PNP open collector 2 outputs + Copy function

# When optional parts are required separately, Options/Part No. use the following part numbers to place an order.

Option
Bracket A With 2 mounting screws of each M3 x 5L, M4 x 5L
Bracket B With 2 mounting screws M4 x 5L
Bracket D With 2 mounting screws of each M3 x 5L, M4 x 5L
Panel mount adapter (Piping: For 01/N01)
Panel mount adapter (Piping: For W1/WF1/M5/C4/C6)
Panel mount adapter + Front protective cover (Piping: For 01/N01)
Panel mount adapter + Front protective cover (Piping: For W1/WF1/M5/C4/C6)

## Unit specifications


Nil	With unit switching function Note 1)
M	Fixed SI unit Note 2)
Р	With unit switching function Note 1) (Initial value psi)

Note 1) Under the New Measurement Law, sales of switches with the unit switching function are not allowed for use in Japan.

Note 2) Fixed unit: For vacuum/compound pressure: kPa For positive pressure: MPa

P			Г	● Mad	e to Order
ΙГ	Ont	ion 2	-	Symbol	Specifications/Description
┚╽	Symbol		1	X501	Lead wire length 3 m
$\dashv$	Nil K	—		X531	M12 4-pin pre-wired connector (Lead wire length 100 mm)
Ok	otion 1*			Refer to	page 17 for details.
Nil	None				
	Bracke	t A			

- Opt	IOII I
Nil	None
A	Bracket A
В	Bracket B
D	Bracket D
Е	Panel mount adapter 01/N01 W1/WF1/M5/C4/C6



Some options are unavailable depending on the piping specifications. Refer to "Combination of piping specifications with option 1 and part numbers of options".



# **Specifications**

	1	Model	ZSE40A (vacuum pressure)	ZSE40AF (compound pressure)	ISE40A (positive pressure)				
Rated pre	essure rang	е	0.00 to -14.69 psi	-14.50 to 14.50 psi	-14.5 to 145.0 psi				
Display/S	et pressure	range	1.45 to -15.23 psi	-15.22 to 15.22 psi	-15.2 to 152.3 psi				
Withstan	d pressure		72.5 psi	72.5 psi	218 psi				
Display/N	/linimum un	it setting	0.01 psi	0.02 psi	0.1 psi				
Applicabl	le fluid		Air, N	lon-corrosive gas, Non-flammabl	le gas				
Power su	pply voltag	е	12 to 24 VDC ±10%, Ripp	ole (p-p) 10% or less (with power	supply polarity protection)				
Current c	onsumptio	n		45 mA or less					
Switch or	utput		NPN or I	PNP open collector 2 outputs (Se	electable)				
	Maximum	load current		80 mA					
	Maximum	applied voltage		28 V (at NPN output)					
	Residual v	/oltage		1 V or less					
	Response	time	2.5 ms (with anti-	-chattering function: 20, 100, 500	), 1000, 2000 ms)				
	Short circ	uit protection	Yes						
Repeat a	ccuracy			±0.2% F.S. ±1 digit					
	Hysteresis	s mode		Note 1)					
Hysteresis	Window c	omparator mode		Variable (0 or above) Note 1)					
	Note 0	Output voltage	4. 5.4.0.57 5.0						
	Note 2) Voltage	(Rated pressure range)	1 to 5 V ±	-2.5% F.S.	0.6 to 5 V ±2.5% F.S.				
	output	Linearity		±1% F.S. or less					
		Output impedance		Approx. 1 k $\Omega$					
Analog output	Note 3)	Output current (Rated pressure range)	4 to 20 mA ±2.5% F.S.		2.4 to 20 mA ±2.5% F.S.				
	Current	Linearity	±1% F.S. or less						
	output	Load impedance	Maximum load impedance: 300 $\Omega$ (Power supply voltage 12 V) 600 $\Omega$ (Power supply voltage 24 V)						
			Minimum Ioa	d impedance: 50 Ω					
Auto-shif	t input		Non-voltage input (Reed o	r Solid state), Low level: 0.4 V or	r less, 5 ms or longer input				
Display			3 1/2-di	git, 7-segment, 2-color LCD (Red	d/Green)				
Display a			±2% F.S.	±1 digit (Ambient temperature o	f 77 ±5°F)				
Indicator	light		Lights up who	en output is turned ON. OUT1, C	OUT2: Orange				
	Enclo	sure		IP65					
	Opera	ating temperature range	Operating: 23 to 122	°F, Stored: 14 to 140°F (No free:	zing or condensation)				
	Opera	ating humidity range	Operating	g/Stored: 35 to 85% RH (No cond	densation)				
Environm		stand voltage	1000 VA	C for 1 minute between live parts	and case				
resistance Insulation resistance			50 M $\Omega$ or more between live parts and case (at 500 VDC Mega)						
	Vibra	tion resistance	10 to 150 Hz at whichever is smaller of 1.5 mm amplitude or 20 m/s² acceleration, in X, Y, Z directions, for 2 hours each (De-energized)						
	Impa	ct resistance	100 m/s <sup>2</sup> in X, Y, Z directions, 3 times each (De-energized)						
Temperat	ture charact	teristics		±2% F.S. (Based on 77°F)					
Lead wire	9		ø3.5, 2 m Conducto	Oilproof heavy-duty vinyl cable or area: 0.15 mm² (AWG26) Ins	ulator O.D.: 0.95 mm				
Standard	s			marking, UL (CSA), RoHS compl					
				value more than the fluctuating width					

Note 1) If the applied voltage fluctuates around the set-value, the hysteresis must be set to a value more than the fluctuating width, otherwise chattering will occur. Note 2) When the analog voltage output is selected, the analog current output cannot be selected.

# **Piping Specifications**

	Part no.	01	N01	W1	WF1	M5	C4	C6
Port size		R1/8 (With M5 female thread)	NPT1/8 (With M5 female thread)	Rc1/8	G1/8	M5 x 0.8 female thread	ø4 one-touch fitting	ø6 one-touch fitting
Material	Sensor pressure receiving area							
of parts in contact with fluid	Piping port		oless nickel plated) ZDC2 ng: HNBR O-ring: HNBR		ZDC2, POM, Stainless steel 304, C3604 (Electroless nickel plated) O-ring: HNBR			
Weight	<b>Weight</b> 78 g 79 g 97 g 104 g 101 g			1 g				




Note 3) When the analog current output is selected, the analog voltage output cannot be selected.


# 2-Color Display High Precision Digital Pressure Switch Series ZSE40A(F)/ISE40A

# **Analog Output**

#### Voltage output



#### **Current output**



Range	Rated pressure range	Α	В	С
For vacuum pressure	0.00 to -14.69 psi	1.47 psi	0	-14.69 psi
For compound pressure	-14.50 to 14.50 psi	_	-14.50 psi	14.50 psi
For positive pressure	-14.5 to 145.0 psi	–14.5 psi	0	145.0 psi

# **Descriptions**

## Output (OUT1) display (Orange)

Lights up when OUT1 is turned ON.

# Output (OUT2) display (Orange)

Lights up when OUT2 is turned ON.

#### △ button

Use this button to select the mode or increase the ON/OFF set-value. It is also used for switching to the peak display mode.



#### LCD

Displays the current pressure, set mode, selected display unit, and error code. Always use red or green display; or switch between green and red according to the output. Four different display settings are available.

## SET button

Use this button to change the mode or confirm the set-value.

#### **▽** button


Use this button to select the mode or decrease the ON/OFF set-value. It is also used for switching to the bottom display mode.



# **Internal Circuits and Wiring Examples**

# -R


# NPN (2 outputs) + Analog voltage output



Max. 28 V, 80 mA Residual voltage 1 V or less

# -S


# NPN (2 outputs) + Analog current output



Max. 28 V, 80 mA Residual voltage 1 V or less

# -R/-S


# NPN (2 outputs) + Auto-shift input



Max. 28 V, 80 mA Residual voltage 1 V or less

# -T PNP (2 outputs) +


Analog voltage output



Max. 80 mA Residual voltage 1 V or less

#### -V


# PNP (2 outputs) + Analog current output



Max. 80 mA Residual voltage 1 V or less


## -T/-V

# PNP (2 outputs) + Auto-shift input



Max. 80 mA Residual voltage 1 V or less


# -X NPN (2 outputs) + Copy function



Max. 28 V, 80 mA Residual voltage 1 V or less

#### -Y

# PNP (2 outputs) + Copy function




Max. 80 mA Residual voltage 1 V or less

# **Dimensions**


# ZSE40A(F)/ISE40A-01 40.2 -N01 M5 x 0.8 thread depth 5 26.2 4.5 30 30 ₽ Piping port 2 x M3 x 0.5 **01**: R1/8 thread depth 4 N01: NPT1/8 ø3.5 Atmospheric vent port ø2.6

# ZSE40A(F)/ISE40A-W1



# **Dimensions**

# ZSE40A(F)/ISE40A-C4





# **Dimensions**


# ZSE40A(F)/ISE40A-01-□-□A□


-N01-□-□A□

## With bracket












# ZSE40A(F)/ISE40A-01-□-□D□

-N01-□-□D□

## With bracket










# **Dimensions**

# ZSE40A(F)/ISE40A-W1-□-□A□ -WF1-□-□A□

With bracket









ZSE40A(F)/ISE40A-W1-□-□B□ -WF1-□-□B□

With bracket






1.6


# 2-Color Display High Precision Digital Pressure Switch Series ZSE40A(F)/ISE40A


# **Dimensions**


ZSE40A(F)/ISE40A-W1- $\square$ - $\square$ D $\square$ -WF1- $\square$ - $\square$ D $\square$ 

# With bracket











**SMC** 


# **Dimensions**


# ZSE40A(F)/ISE40A-01-□-□E□ -N01-□-□E□

# **Panel mounting**












# ZSE40A(F)/ISE40A-01-U-UFU


-N01-□-□F□

Panel mounting + Front protective cover












# **Dimensions**

# ZSE40A(F)/ISE40A-W1-□-□E□ -WF1-□-□E□

# **Panel mounting**










# $\textbf{ZSE40A(F)/ISE40A-W1-} \square - \square F \square$

-WF1-□-□F□

# Panel mounting + Front protective cover








**SMC** 


# **Dimensions**


# ZSE40A(F)/ISE40A-C4-□E□

-C6-□E□

## **Panel mounting**










# ZSE40A(F)/ISE40A-C4-□F□

-C6-□F□


Panel mounting + Front protective cover







# **Dimensions**



Note) This is the minimum value for the piping method 01 or N01.

Take the piping material and tubing into account for design. When the corner is to have radius, it must be R3 or less.

**SMC** 


#### **Function Details**


## A Copy function (F97)

The settings of the master pressure switch can be copied to the slave pressure switches.

This can reduce the labor for setting and prevent the entry of incorrect set-values.

The set-value can be copied to up to 10 switches simultaneously. (Maximum communication distance 4 m)






- 1) Wire as shown in the left figure.
- Select the slave switch which is to be the master, and change it into a master using the buttons. (In the default setting, all switches are set as slaves.)
- 3) Press the S button of the master switch to start copying.

# B Auto-preset function (F 4)

Auto-preset function, when selected in the initial setting, calculates and stores the set-value from the measured pressure. The optimum set-value is determined automatically by repeating vacuum and break with the target work piece several times.

#### **Suction Verification**




#### Formula for Obtaining the Set-Value

P_1 or P_2	H_1 or H_2
P_1 (P_2) = A - (A-B)/4 n_1 (n_2) = B + (A-B)/4	H_1 (H_2) = (A-B)/2

# C Display calibration function (F 6)

Fine adjustment of the indicated value of the pressure sensor can be made within the range of  $\pm 5\%$  of the read value. (The scattering of the indicated value can be eliminated.)



Note) When the display calibration function is used, the set pressure value may change  $\pm 1$  digit.

## D Peak and bottom display function

This function constantly detects and updates the maximum (minimum) value and allows to hold the maximum (minimum) pressure value.

When the riangle riangle buttons are simultaneously pressed for 1 second or longer, while "holding", the hold value will be reset.

#### E Key lock function

This function prevents incorrect operations such as accidentally changing the set-value.

#### F Zero-clear function

This function clears and resets the zero value on the display of measured pressure.

For the pressure switch with analog output, the analog output shifts according to the indication. The indicated value can be adjusted within  $\pm 7\%$  F.S. of the pressure when ex-factory. (ZSE40AF (for compound pressure)  $\pm 3.5\%$  F.S.)



The  $F\Box$  in ( ) shows the function code number. Refer to the Operation Manual for the details of operation procedures and function codes.

## **G** Error indication function

Error name	Error code	Description	Remedy
Overcurrent	Er 1	Load current of switch output (OUT1) exceeds 80 mA.	Turn the power off and remove the output factor for
error	Er2	Load current of switch output (OUT2) exceeds 80 mA.	the overcurrent. Then, turn the power on.
Residual pressure error	Er3	During zero-clear operation, pressure over ±7% F.S. is applied. (ZSE40AF (compound) ±3.5% F.S.) After 1 second, the mode will reset to measurement mode. ±1% F.S. of the zero-clear range varies between individual products.	Perform zero-clear operation again after restoring the applied pressure to an atmospheric pressure condition.
Applied	XXX	Supply pressure exceeds the maximum set pressure.	Reset applied pressure to a level within the set
pressure error		Supply pressure is below the minimum set pressure.	pressure range.
Auto-shift error	or	The value measured at the time of auto-shift input is outside the set pressure range.  * After displaying the error code for about 1 second, the switch returns to the measuring mode.	The controller does not respond to the auto-shift signal. Check the equipment and machinery for this point.
System error	84 84 84 84 84 84 84 84 84 84 84 84 84 8	Internal data error	Turn the power off and turn it on again. If the failure cannot be solved, ask SMC for repair.

If the above remedy cannot recover the operation, ask SMC for repair.


#### H Anti-chattering function (F 3)

A large bore cylinder or ejector consumes a large volume of air in operation and may experience a temporary drop in the supply pressure. This function prevents detection of such temporary drops in the supply pressure as an error.

Available response time settings 20 ms, 100 ms, 500 ms, 1000 ms, 2000 ms

#### <Principle>

This function averages pressure values measured during the response time set by the user and then compares the average pressure value with the pressure set point value to output the result on the switch.



#### Display unit switching function (F 0)

Display units can be switched with this function.

Display unit	Р	Я	5F	ЬЯг	P5 ,	ıπΗ	ňňX
Minimum unit setting	kPa	MPa*	kgf/cm <sup>2</sup>	bar	psi	inHg	mmHg
ZSE40A (vacuum pressure)	0.1	0.001	0.001	0.001	0.01	0.1	1
<b>ZSE40AF</b> (compound pressure)	0.1	0.001	0.001	0.001	0.02	0.1	1
ISE40A (positive pressure)	1	0.001	0.01	0.01	0.1		

<sup>\*</sup> The ZSE40A (vacuum pressure) and ZSE40AF (compound pressure) will have different setting and display resolution when the unit is set to MPa.



#### **Function Details**

The F $\square$  in ( ) shows the function code number. Refer to the Operation Manual for the details of operation procedures and function codes.

### J Power-saving mode (F80)

Power-saving mode can be selected.

It shifts to the power-saving mode without button operation for 30 seconds. It is set to the normal mode (Power-saving mode is OFF.) when ex-factory. (Decimal points and operation indicator light (only when the switch output is turned ON.) blink in the power-saving mode.)


## K Secret code setting (F81)

It can be set whether secret code input is required or not when key is locked. It is set to input no secret code when ex-factory.

## L Auto-shift function (F 5)

When there are large fluctuations in the supply pressure, the switch may fail to operate correctly. The auto-shift function compensates such supply pressure fluctuations. It measures the pressure at the time of auto-shift signal input and uses it as the reference pressure to correct the set-value on the switch.

#### Set-value correction by auto-shift function



#### \* Rectified value

When the auto-shift is selected, "papa" will be displayed for about 1 second, and the pressure value at that point will be saved as a rectified value, "Based on the saved rectified values, the set-value. When off " ' ?", " ?", " ?", " ?", " ?", " ?", and " " will likewise be rectified.

Note) When an output is reversed, "n-1", "H-1", "n-2", "H-2" will be rectified.

#### Possible Set Range for Auto-Shift Input

	Regulating pressure range	Possible set range
Compound pressure	-15.22 to 15.22 psi	-30.4 to 30.4 psi
Vacuum pressure	1.45 to -15.23 psi	16.68 to -16.68 psi
Positive pressure	-15.2 to 152.3 psi	-167.5 to 167.5 psi

#### Auto-shift zero

The basic function of auto-shift zero is the same as the function for auto-shift. Also, it corrects values on the display, based on a pressure value of " ", when the auto-shift is selected.



# Series ZSE40A(F)/ISE40A Made to Order



Please contact SMC for detailed dimensions, specifications, and lead times.




Symbol -X501

Lead wire is 3 meters.

**How to Order** 






Symbol

-X531


# M12 4-pin pre-wired connector

# **How to Order**




Output specifications •

X: NPN open collector 2 outputs
Y: PNP open collector 2 outputs



Pin arrangement





# **Safety Instructions**

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC), American National Standards Institute (ANSI)\*1) and other safety regulations.

\*1) ISO 4414: Pneumatic fluid power – General rules relating to systems.

ISO 4413: Hydraulic fluid power – General rules relating to systems.

IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)

ISO 10218-1: Manipulating industrial robots - Safety.

ANSI / (NFPA) T2.25.1 R2: Pneumatic fluid power - Systems standard for industrial machinery.

NFPA (Fluid) T2.24.1 R1: Hydraulic fluid power - Systems standard for stationary industrial machinery.

NFPA 79: Electrical Standard for Industrial Machinery.

ANSI / RIA / ISO 10218 -1: Robots for Industrial Environment - Safety Requirements - Part 1 - Robot.

Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate **⚠** Caution:

**⚠** Warning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or

serious injury.

Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

# **⚠** Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
  - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
  - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
  - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
  - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
  - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.





# **⚠** Caution

#### 1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

# Limited warranty and Disclaimer/Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements". Read and accept them before using the product.

# **Limited warranty and Disclaimer**

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered.\*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided.
  - This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
  - \*2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered.

Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

# **Compliance Requirements**

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.



# Series ZSE40A(F)/ISE40A Specific Product Precautions 1

Be sure to read before handling.

Refer to back pages 1 and 2 for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) for Pressure Switches Precautions.

#### Handling

# **⚠** Caution

- Do not drop, bump, or apply excessive impacts (100 m/s²) while handling. Although the body of the sensor may not be damaged, the internal parts of the sensor could be damaged and lead to a malfunction.
- The tensile strength of the cord is 49 N. Applying a greater pulling force on it can cause a malfunction. When handling, hold the body of the sensor—do not dangle it from the cord.
- 3. Do not exceed the screw-in torque of 7 to 9 N·m when connecting the pipe to the switch. Exceeding this torque may cause the switch to malfunction.
- 4. Do not use pressure sensors with corrosive and/or flammable gases or liquids.

#### Connection

# **⚠** Caution

- 1. Incorrect wiring can damage the switch and cause a malfunction or erroneous switch output.
- 2. Connections should be done while the power is turned off.
- 3. Wire separately from power lines and high voltage lines, avoiding wiring in the same conduit with these lines. Malfunctions may occur due to noise from these other lines.
- 4. If a commercial switching regulator is used, make sure that the F.G. terminal is grounded.

## **Operating Environment**


# \land Warning

- This pressure switch is CE marked; however, it is not equipped with surge protection against lightning. Lightning surge countermeasures should be applied directly to system components as necessary.
- This pressure switch does not have an explosion proof rating. Never use in the presence of an explosive gas as this may cause a serious explosion.

#### **Operating Environment**

# **⚠** Caution

- 1. Do not use the product in a place where it could be splashed by oils or solvents.
- 2. When this pressure switch is used in a place where water and dust splash on, water and dust may enter inside the switch through the atmospheric vent port. Insert a Ø4 tube (I.D. Ø2.5) into the atmospheric vent port, and bring piping of the opposite side up to the safe position to keep it from water and dust. Do not bend the tube or close the hole of it. It causes malfunction with the measurement of positive pressure.



- \* Make sure that the tube is inserted to the end of the atmospheric vent port.
- \* Use SMC tubing, TU0425. (Material: Polyurethane, Tube O.D. ø4, I.D. ø2.5)
- 3. Take measures against static electricity with equipment when this switch is used in connection with resin piping. Also, the ground should be separate from that of the units that generate strong electromagnetic noise or high frequency, otherwise, the switch can be damaged by static electricity.






# Series ZSE40A(F)/ISE40A Specific Product Precautions 2

Be sure to read before handling.

Refer to back pages 1 and 2 for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) for Pressure Switches Precautions.


#### Mounting

# 



#### 2. Mounting with bracket

Mount a bracket to the using two mounting screws and install on piping. The switch can be installed horizontally depending on the installation location.



The tightening torque for bracket mounting screw should be 0.5 to 0.7 N·m for M3 and 1.4 to 1.6 N·m for M4.

## **Set Pressure Range and Rated Pressure Range**


# **⚠** Caution

#### Set the pressure within the rated pressure range.

The set pressure range is the range of pressure that is possible in setting.

The rated pressure range is the range of pressure that satisfies the specifications (accuracy, linearity, etc.) on the switch.

Although it is possible to set a value outside the rated pressure range, the specifications will not be guaranteed even if the value stays within the set pressure range.



# **Related Equipment**

# 2-Color Display High Precision Digital Pressure Switch ZSE/ISE30A





Series	Туре	Rated pressure range	
ZSE30AF	Compound pressure	-14.50 to 14.50 psi	
ZSE30A	Low pressure/vacuum	0.00 to −14.65 psi	
ISE30A	Positive pressure	–14.5 to 145.0 psi	
Features	<ul> <li>With one-touch fitting (Straight, Elbow)</li> <li>Space-saving, capable of vertical and horizontal contact mounting</li> <li>With display calibration function</li> <li>Simultaneous copying is possible for maximum 10 units.</li> <li>IP40</li> </ul>		

# 2-Color Display Digital Pressure Switch ZSE/ISE80



Series	Туре	Rated pressure range	
ZSE80F	Compound pressure	-14.50 to 14.50 psi	
ZSE80	Vacuum pressure	0.00 to -14.65 psi	
ISE80	Positive pressure	-14.5 to 145.0 psi	
ISE80H	Positive pressure	-14.5 to 290 psi	
Features	<ul> <li>Suitable for a wide variety of fluids with stainless diaphragm</li> <li>IP65</li> <li>RoHS compliant</li> <li>Low leakage. VCR®, Swagelok® compatible fittings can be selected.</li> <li>With one-touch fittings (Straight, Elbow)</li> <li>Back piping, underside piping</li> </ul>		

<sup>\*</sup> VCR® and Swagelok® are trademarks of Swagelok Company.

# Global Manufacturing, Distribution and Service Network

# Worldwide Subsidiaries

**EUROPE** 

**AUSTRIA** 

SMC Pneumatik GmbH (Austria)

**BELGIUM** 

SMC Pneumatics N.V./S.A.

**BULGARIA** 

SMC Industrial Automation Bulgaria EOOD

**CROATIA** 

SMC Industrijska Automatika d.o.o.

**CZECH** 

SMC Industrial Automation CZ s.r.o.

**DENMARK** 

SMC Pneumatik A/S

**ESTONIA** 

SMC Pneumatics Estonia

**FINLAND** 

SMC Pneumatics Finland OY

**FRANCE** 

SMC Pneumatique S.A.

**GERMANY** 

SMC Pneumatik GmbH

**GREEK** SMC Hellas EPE

HUNGARY SMC Hungary Ipari Automatizálási Kft.

**IRELAND** SMC Pneumatics (Ireland) Ltd.

**ITALY** 

SMC Italia S.p.A.

LATVIA

SMC Pneumatics Latvia SIA

LIFTUVA

SMC Pneumatics Lietuva, UAB

**NETHERLANDS** 

SMC Pneumatics BV

NORWAY

SMC Pneumatics Norway A/S

**POLAND** 

SMC Industrial Automation Polska Sp.z.o.o.

**ROMANIA** 

SMC Romania S.r.I.

RUSSIA

SMC Pneumatik LLC.

SI OVAKIA

SMC Priemyselná Automatizáciá, s.r.o.

SLOVENIA

SMC Industriiska Avtomatika d.o.o.

SPAIN/PORTUGAL SMC España, S.A.

**SWEDEN** 

SMC Pneumatics Sweden AB

**SWITZERLAND** 

SMC Pneumatik AG

SMC Pneumatics (U.K.) Ltd.

**ASIA** 

CHINA SMC (China) Co., Ltd.

HONG KONG

SMC Pneumatics (Hong kong) Ltd.

INDIA

SMC Pneumatics (India) Pvt. Ltd.

JAPAN

**SMC** Corporation

MALAYSIA

SMC Pneumatics (S.E.A.) Sdn. Bhd.

**PHILIPPINES** 

SMC Pneumatics (Philippines), Inc.

**SINGAPORE** 

SMC Pneumatics (S.E.A.) Pte. Ltd.

SOUTH KOREA

SMC Pneumatics Korea Co., Ltd.

**TAIWAN** 

SMC Pneumatics (Taiwan) Co., Ltd.

**THAILAND** 

SMC Thailand Ltd.

NORTH AMERICA

SMC Pneumatics (Canada) Ltd.

SMC Corporation (Mexico) S.A. DE C.V.

SMC Corporation of America

#### **SOUTH AMERICA**

ARGENTINA

SMC Argentina S.A.

**BOLIVIA** 

SMC Pneumatics Bolivia S.R.L.

SMC Pneumaticos do Brazil Ltda.

CHILE

SMC Pneumatics (Chile) S.A.

**VENEZUELA** 

SMC Neumatica Venezuela S.A.

#### **OCEANIA**

**AUSTRALIA** 

SMC Pneumatics (Australia) Pty. Ltd.

**NEW ZEALAND** 

SMC Pneumatics (N.Z.) Ltd.

# U.S. & Canadian Sales Offices

EAST WEST **Atlanta** Austin **Dallas** 

Charlotte Los Angeles **Nashville Phoenix New Jersey Portland** 

Richmond Rochester

**Tampa** 

**Detroit** 

**Boston** 

MIDWEST

Chicago Cincinnati **Toronto** Cleveland


Indianapolis Milwaukee Minneapolis

St. Louis

CANADA

San Francisco

Montreal Vancouver Windsor





**SMC Corporation of America** 

10100 SMC Blvd., Noblesville, IN 46060 www.smcusa.com

(800) SMC.SMC1 (762-7621)

© 2009 SMC Corporation of America, All Rights Reserved.

For International inquires: www.smcworld.com All reasonable efforts to ensure the accuracy of the information detailed in this catalog were made at the time of publishing. However, SMC can in no way warrant the information herein contained as specifications are subject to change without notice.