



ENGLISH

Datasheet

Stock No. 1864630

RS PRO Rechargeable Site Light with Power Bank



1200
LUMENS



2 Brightness
Settings



180° Adjustable
Handle



IK08
Impact Resistant



USB Power Bank
Output: 5v



USB Charging
Cable Inc.



Technical Data

1200 Lumen white COB LED
Robust die cast aluminium construction
With rubberised plastic corner protectors
USB Powerbank for device charging
180° Adjustable handle/stand
LED Colour Temperature 6500k
Wide 120° beam angle spread
Useful battery level indicator lights
IP65 dust & water resistant
IK08 Impact resistant
2m Drop proof

Operating Temperature: -10° to +40°

Product Size: 125 x 170 x 43 mm

Product Weight: 800g

Battery: Rechargeable High power 3.7v 4400mAh Li-ion battery

Charger: 1m USB charging cable (Included)

Charging time: approx 5 hours

LED charging indicators: 4 separate green lights to indicate charging status

Battery power indicators: 4 separate green lights to indicate power remaining in battery

Runtimes

100% - 3 hours

50% - 6 hours

Operation

Press the Switch on the back of the Light Switch Sequence: High > Low > Off
[If left in any mode for more than 3 seconds, the next press will turn OFF]

ADVICE & IMPORTANT INFORMATION!

- Do not look directly at the LED.
- Do not operate in direct sunlight or extreme temperature conditions (below -10°C or above 40°C).
- The LED will become hot when switched on; do not touch and do not place face down on any surface – risk of fire!
- Do not use the device if there is any visible damage to the housing, charge base, plug or cable.
- Do not use the lamp in the immediate vicinity of flammable materials or gases.
- Children under 12 years of age should only use the product under adult supervision.
- Before cleaning the lamp, disconnect the charge cable or remove from charge base. Clean with a dry or slightly moist, clean, lint-free cloth and a mild detergent if required. Do not use cleaners that contain abrasives or solvents.
- Do not open, disassemble or attempt to modify the product; this will void the warranty and can be dangerous.
- Improper use or modification is not covered under the warranty.
- Ensure the lens does not come into contact with hard/sharp objects; damage to the lens may affect light output.
- To maintain rechargeable batteries, distributors should recharge the battery every 6 months and users should recharge every 3 months if not using for an extended period.
- Fully charge the product before storage.
- The rechargeable battery will reach optimum performance only after several complete charging and discharging cycles.
- Protect the battery from heat, intense sunlight, fire, water and moisture – danger of explosion!
- If the battery is damaged, fluids can leak out. AVOID contact as this can lead to skin irritation and/or burns. If skin contact happens, rinse thoroughly with water. If irritation persists, seek medical advice. Also seek immediate medical assistance if battery fluid comes into contact with the eyes.
- Do not dispose of this device in normal household waste. It must be disposed of via an authorised disposal centre or at your local waste disposal unit.
- Please recycle packaging where possible.
- Keep these instructions for future reference or for subsequent possessors.

