



Datasheet
196-4197
RSPRO-F22R



USB Rechargeable Focus Flashlight

 **3200**
LUMENS

 **4** Light
Settings

 **IPX7**
Water Proof

 USB Power Bank
Output: 5v

 USB Charging
Cable Inc.



Technical Data

3200 Lumen white Osram P8 LED
Tough aircraft-grade aluminium construction
Easy twist flood-to-spot focus
White daylight 5500k colour temperature
Glow-in-the-Dark reflector
Easy press rubberised switch on torch body
Flawless domed lens for long distance beam
Safety wrist strap included
Power Bank feature
Charging indicator lights
1m impact resistant

Product Size: 47 x 47 x 242 mm




Product Weight: 402g

Battery: 2 x 3.6v 2000mAh 18650 Li-ion Batteries with 2.8V protection board (included)

Charger: Micro-USB cable (included) Max 1A

Charging Time: approx 4.5 hrs

LED Charging Indicator: Red-Charging, Green-Fully charged

MODE			
HIGH	3200 lm	250 m	1.5 hrs
MEDIUM	320 lm	88 m	3.5 hrs
LOW	50 lm	30 m	50 hrs
STROBE	--	--	4 hrs

Operation

High > Medium > Low > Off

If left in any MODE for 8 or more seconds, the next press will turn OFF.

Strobe Function - double press at any time to enter strobe mode

ADVICE & IMPORTANT INFORMATION!

- Do not look directly at the LED.
- Do not operate in direct sunlight or extreme temperature conditions (below -10°C or above 40°C).
- The LED will become hot when switched on; do not touch and do not place face down on any surface - risk of fire!
- Do not use the device if there is any visible damage to the housing or cable.
- The aluminium housing can get warm. If it gets too hot turn down the brightness or turn off and allow to cool.
- Do not use the lamp in the immediate vicinity of flammable materials or gases.
- Children under 12 years of age should only use the product under adult supervision.
- Before cleaning the product, disconnect the charge cable. Clean with a dry or slightly moist, clean, lint-free cloth and a mild detergent if required. Do not use cleaners that contain abrasives or solvents.
- Do not attempt to modify the product; this will void any warranty and can be dangerous.
- Improper use or modification is not covered under warranty.
- Ensure the lens does not come into contact with hard/sharp objects; damage to the lens may affect light output.
- To maintain rechargeable batteries, distributors should recharge the battery every 6 months and users should recharge every 3 months if not using for an extended period.
- Fully charge the product before storage.
- The rechargeable battery will reach optimum performance only after several complete charging and discharging cycles.
- Protect the battery from heat, intense sunlight, fire, water and moisture - danger of explosion!
- If the battery is damaged, fluids can leak out. AVOID contact as this can lead to skin irritation and/or burns. If skin contact happens, rinse thoroughly with water. If irritation persists, seek medical advice. Also seek immediate medical assistance if battery fluid comes into contact with the eyes.
- Do not dispose of this device in normal household waste. It must be disposed of via an authorised disposal centre or at your local waste disposal unit.
- Please recycle packaging where possible. Keep these instructions for future reference or for subsequent possessors.

