



ENGLISH

Datasheet

Stock No. 1864627


RS PRO Rechargeable Laser Pointer Inspection Light

 **300**
LUMENS

 **100** Lumen
Torch

 Laser
Pointer

 **180°** Adjustable
Handle

 Strong Magnet
in Base

 USB Charging
Cable Inc.



Technical Data

Floodlight - 300 Lumen White COB LED

Flashlight - 100 Lumen White SMD LED

With red Laser pointer

High impact ABS and Rubber housing with PC lens

180° Adjustable/Folding handle

Super strong magnetic base

Rotating nylon hanging hook

80+ CRI

LED Colour Temperature 6500k

IP54 dust & water resistant

IK07 shock proof

Operating Temperature: -10° to +40°

Product Size: 160 x 51 x 33mm

Product Weight: 168g

Battery: Rechargeable high quality 3.7v 1100mAh Li-ion

Charger: 1m Micro-USB cable (Included)

Charging time: approx 2.5 hours

LED charging indicator: Red-Charging, Green-Fully charged

Runtimes

Flashlight: 100 lumen - 5-5hrs

Floodlight: 300 lumen - 3 hrs

Operation

Left Switch - Flashlight > Floodlight > Off

Right Switch - Laser Pointer (DO NOT point at anyone)

ADVICE & IMPORTANT INFORMATION!

- Do not look directly at the LED.
- Do not operate in direct sunlight or extreme temperature conditions (below -10°C or above 40°C).
- The LED will become hot when switched on; do not touch and do not place face down on any surface - risk of fire!
- Do not use the device if there is any visible damage to the housing or cable.
- Do not use the lamp in the immediate vicinity of flammable materials or gases.
- Children under 12 years of age should only use the product under adult supervision.
- Before cleaning the product, disconnect the charge cable. Clean with a dry or slightly moist, clean, lint-free cloth and a mild detergent if required. Do not use cleaners that contain abrasives or solvents.
- Do not open, disassemble or attempt to modify the product; this will void any warranty and can be dangerous.
- Improper use or modification is not covered under warranty.
- Ensure the lens does not come into contact with hard/sharp objects; damage to the lens may affect light output.
- To maintain rechargeable batteries, distributors should recharge the battery every 6 months and users should recharge every 3 months if not using for an extended period.
- Fully charge the product before storage.
- The rechargeable battery will reach optimum performance only after several complete charging and discharging cycles.
- Protect the battery from heat, intense sunlight, fire, water and moisture - danger of explosion!
- If the battery is damaged, fluids can leak out. AVOID contact as this can lead to skin irritation and/or burns. If skin contact happens, rinse thoroughly with water. If irritation persists, seek medical advice. Also seek immediate medical assistance if battery fluid comes into contact with the eyes.
- Do not dispose of this device in normal household waste. It must be disposed of via an authorised disposal centre or at your local waste disposal unit.
- Please recycle packaging where possible. Keep these instructions for future reference or for subsequent possessors.

