
# Modular Type Regulator with Built-in Pressure Gauge **ARG Series**

				AC-A
Regulator with Built-in Pressure Gauge	Model	Port size	Accessory	AF-A
ARG Series				AF⊡-A
	ARG20	1/8, 1/4		AR-A
			-	AL-A
	ARG30	1/4, 3/8		AW-A
				AC-B
				AF-A
	ARG40	1/4, 3/8, 1/2		AF⊡•A
Pages 620 to 623 Regulator with Built-in Pressure			Bracket	<b>AR</b> :₿
Gauge with Backflow Function	ARG20K	1/8, 1/4	Set nut for changing the mounting angle	AL-A
			of pressure gauges	AW:8
				AW□
- 截至35%。 - 私社会の定任会	ARG30K	1/4, 3/8		A□G
				E
	ARG40K	1/4, 3/8, 1/2		AV
Pages 624 to 628				AF

# **Regulator with Built-in Pressure Gauge** ARG20/30/40 Series



Mounting angles other than 45°, 135°, 225° and 315° are available through the Made to Order (page 630)

Possible to change to the optional mounting angles

For details, refer to page 642, "Procedure for replacing or changing the mounting angle of a pressure gauge".

Opt	tion/Semi-standard Combinations			2				t available ith NPT thread
	Combination	Symbol	Op	tion	Sem	ii-stan	dard	Applicable regulator
Opti	ion/Semi-standard specifications	.,	в	н	1	Ν	Z	ARG20 to 40
Option	With bracket	в			Ø	Ø	Δ	O
Opt	With set nut	н			0	Ø	Δ	O
, p	0.02 to 0.2 MPa setting	-1	0	O		0	Δ	O
Semi- standard	Non-relieving type	-N	O	O	O		Δ	0
sta	Name plate and pressure gauge in imperial units (psi)	-Z	$\triangle$	Δ	Δ	Δ		Δ

O: Combination available

ARG40

### Regulator with Built-in Pressure Gauge ARG20/30/40 Series

#### Standard Specifications


Model	ARG20	ARG30	ARG40					
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2					
Fluid		Air						
Proof pressure		1.5 MPa		AC				
Maximum operating pressure		1.0 MPa						
Regulating pressure range		0.05 to 0.85 MPa		AF				
Relief pressure	Set pressure + 0.05 MPa (at relief flow rate of 0.1 L/min (ANR))							
Ambient and fluid temperature	· · · · · · · · · · · · · · · · · · ·	-5 to 60°C (With no freezing)		AF				
Construction		Relieving type						
Weight (kg)	0.21	0.40	0.57					
				⊣  AR				


#### **Option Part No.**


	_		Applicable model				AW-A
Option				ARG20	ARG30	ARG40	AC-B
Bracket ass	embly <sup>(1)</sup>			ARG20P-270AS	ARG30P-270AS	ARG40P-270AS	
Set nut				ARG20P-260S	ARG30P-260S	ARG40P-260S	AF-A
	Pressure	Standard	0 to 1.0 MPa	GB2-10AS	GB3-10AS	GB4-10AS	
Pressure	gauge		0 to 0.3 MPa	GB2-3AS	GB3-3AS	GB4-3AS	]  AF⊡-A
gauge	display	Semi-standard	0 to 150 psi	GB2-P10AS	GB3-P10AS	GB4-P10AS	
	range		0 to 45 psi	GB2-P3AS	GB3-P3AS	GB4-P3AS	<b>AR</b> :₿


Note 1) Assembly includes a bracket and set nuts.

### Flow Rate Characteristics (Representative Values)












AL-A


AW-A

AL-A AW:


AW

### Pressure Characteristics (Representative Values)





Conditions: Inlet pressure 0.7 MPa, Outlet pressure 0.2 MPa, Flow rate 20 L/min (ANR)



**SMC** 

## ARG20/30/40 Series

### ▲ Specific Product Precautions

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 387 to 391 for F.R.L. Precautions.

#### Selection

### ⚠Warning

 Releasing the inlet pressure does not mean that all residual pressure is released (the outlet pressure cannot be released). When releasing residual pressure, use a regulator with a backflow function.

## Mounting and Adjustment

### A Warning

- Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

### A Caution

1. Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure.


Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.


- Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
- Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).




 When using the regulator between a solenoid valve and an actuator, check the pressure gauge periodically.

### Construction







### **Component Parts**

No.	Description		Material		Note	
INO.	Description	ARG20	ARG40	Note		
1	Body		ADC		Platinum silver	
2	Bonnet		PBT			
3	Knob		Black			

#### **Replacement Parts**


**SMC** 


No.	Description	Material	<u></u>		Part no.	
INO.	Description	wateriai	Qty.	ARG20	ARG30	ARG40
4	Valve	Brass, HNBR	1	AR20P-410S	AR30P-410S	AR40P-410S
5	Diaphragm assembly	Weatherability NBR	1	AR20P-150AS	AR30P-150AS	AR40P-150AS
6	Valve guide assembly	POM, NBR	1	AR20P-050AS	AR30P-050AS	AR40P-050AS
7	Pressure gauge cover	PC	1	ARG20P-400S	ARG30P-400S	ARG40P-400S
8	Pressure gauge	_	1	GB2-10AS	GB3-10AS	GB4-10AS
9	Clip	Stainless steel	1	ARG20P-420S	ARG30P-420S	ARG40P-420S

Note) Only the standard part numbers are listed in the pressure gauges. For the optional part numbers, refer to page 621.


## Regulator with Built-in Pressure Gauge ARG20/30/40 Series


### Dimensions





Panel fitting dimension





ARG20 to 40: Max. 3.5

	Standard specifications						Option specifications													
Model P	р	•	Note) B	2	D	F	E	G		Pa	nel mo	unt				Bra	cket m	ount		
	F	A	P	C		-		u u	н	J	К	L	М	Ø	U	Т	S	R	٧	Ν
ARG20	1/8, 1/4	40	114	26.5	57	45	47	M39 x 1.5	38	52.5	39.5	19.5	6	48	65	10.4	5.4	60	2.3	35
ARG30	1/4, 3/8	53	138.5	31	59	58	59	M50 x 1.5	50	65	50.5	25	7	58.5	75	10.5	6.5	70	2.3	45
ARG40	1/4, 3/8, 1/2	70	150.5	36	68	70	70	M55 x 1.5	54	70	55.5	27.5	7	65.5	85	12.5	8.5	75	2.3	50

Note) Full length dimension B is measured when the knob is unlocked.

AC-A Af-a

AFD-A

AR-A

AL-A

AW-A

AC-B

AF-A

AF - A

AR∄


AL-A

AW:

AW□ A□G E□

AV AF

## **Regulator with Built-in Pressure Gauge** with Backflow Function ARG20K/30K/40K Series



5

Opti

Semi-standard

## Regulator with Built-in Pressure Gauge with Backflow Function ARG20K/30K/40K Series

#### **Standard Specifications**

Model	ARG20K	ARG30K	ARG40K	1						
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	]						
Fluid	Air									
Proof pressure		1.5 MPa								
Maximum operating pressure		1.0 MPa		AC						
Regulating pressure range (1)		0.05 to 0.85 MPa		AF						
Relief pressure	Set pressure -	+ 0.05 MPa (at relief flow rate of 0.1	L/min (ANR))							
Ambient and fluid temperature		-5° to 60°C (With no freezing)		AF						
Construction		Relieving type								
Weight (kg)	0.21	0.40	0.57	]   AF						


Note 1) Set the inlet pressure to 0.05 MPa or higher than the set pressure.


#### **Option Part No.**

Option Pa	art No.						AW-A
			Applicable model				AW-A
Option				ARG20K	ARG30K	ARG40K	AC-B
Bracket ass	embly (1)			ARG20P-270AS	ARG30P-270AS	ARG40P-270AS	
Set nut				ARG20P-260S	ARG30P-260S	ARG40P-260S	AF-A
	Durana	Standard	0 to 1.0 MPa	GB2-10AS	GB3-10AS	GB4-10AS	1
Pressure	Pressure gauge		0 to 0.3 MPa	GB2-3AS	GB3-3AS	GB4-3AS	AF⊡-A
gauge	display	Semi-standard	0 to 150 psi	GB2-P10AS	GB3-P10AS	GB4-P10AS	
	range		0 to 45 psi	GB2-P3AS	GB3-P3AS	GB4-P3AS	<b>AR</b> :₿


Note 1) Assembly includes a bracket and set nuts.

### Flow Rate Characteristics (Representative Values)







Condition: Inlet pressure 0.7 MPa




### Pressure Characteristics (Representative Values)





Conditions: Inlet pressure 0.7 MPa, Outlet pressure 0.2 MPa, Flow rate 20 L/min (ANR)



Dressure 0.7 MPa



AF


AL-A

AL-A



### ARG20K/30K/40K Series

### **Working Principle**








Figure 1

Normal

Pressure in

(IN) diaphragm chamber





When the inlet pressure (P1) is higher than the regulating pressure, the check valve 2 closes and operates as a normal regulator (Figure 1).

When the inlet pressure (P1) is shut off and released, the check valve O opens and the pressure in the diaphragm chamber O is released into the inlet side (Figure 2). This lowers the pressure in the diaphragm chamber O and the force generated by the pressure regulator spring O lifts the diaphragm. Valve O opens through the stem, and the outlet pressure is released to the inlet side (Figure 3).

### ▲ Specific Product Precautions

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 387 to 391 for F.R.L. Precautions.

Mounting and Adjustment

- Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

### **▲**Caution

1. Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure.

Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.

- Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
- Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).




Maintenance


### A Warning


 When using the regulator between a solenoid valve and an actuator, check the pressure gauge periodically.
 Sudden pressure fluctuations may shorten the durability of the pressure gauge.

## Regulator with Built-in Pressure Gauge with Backflow Function ARG20K/30K/40K Series

### Construction







#### **Component Parts**

No.	Description		Material		Note	
INO.	Description	ARG20K	ARG30K	ARG40K	Note	
1	Body		Platinum silver			
2	Bonnet		PBT Blac			
3	Knob		Black			


#### **Replacement Parts**


No.	Description	Material	<b>A</b> .		Part no.	
INO.	Description	Material	Qty.	ARG20K	ARG30K	ARG40K
4	Valve	Brass, HNBR	1	AR20P-410S	AR30P-410S	AR40P-410S
5	Diaphragm assembly	Weatherability NBR	1	AR20P-150AS	AR30P-150AS	AR40P-150AS
6	Valve guide assembly	POM, NBR	1	AR20P-050AS	AR30P-050AS	AR40P-050AS
7	Pressure gauge cover	PC	1	ARG20P-400S	ARG30P-400S	ARG40P-400S
8	Pressure gauge (1)	-	1	GB2-10AS	GB3-10AS	GB4-10AS
9	Clip	Stainless steel	1	ARG20P-420S	ARG30P-420S	ARG40P-420S
10	Check valve assembly (2)	_	1		AR20KP-020AS	

Note 1) Only the standard part numbers are listed for the pressure gauges. For the optional part numbers, refer to page 625. Note 2) Check valve assembly contains check valve, check valve cover and its screws (2 pcs). AC-A AF-A AFD-A AR-A AL-A AW-A AC-B AF-A AF - A AR: AL-A AW: AW□ A⊡G E AV AF


### ARG20K/30K/40K Series

### Construction





Panel fitting dimension






Plate thickness ARG20K to 40K: Max. 3.5


			Standa	ard spe	cificatio	ons			Option specifications											
Model		·	Panel mount Bracket mount																	
	F	A	P	C		-		FG	н	J	К	L	М	Ø	U	Т	S	R	٧	Ν
ARG20K	1/8, 1/4	40	114	26.5	57	45	47	M39 x 1.5	38	52.5	39.5	19.5	6	48	65	10.4	5.4	60	2.3	35
ARG30K	1/4, 3/8	53	138.5	31	59	58	59	M50 x 1.5	50	65	50.5	25	7	58.5	75	10.5	6.5	70	2.3	45
ARG40K	1/4, 3/8, 1/2	70	150.5	36	68	70	70	M55 x 1.5	54	70	55.5	27.5	7	65.5	85	12.5	8.5	75	2.3	50

Note) Full length dimension B is measured when the knob is unlocked.



### Regulator with Built-in Pressure Gauge *ARG20/30/40* Made to Order Specifications:

Please contact SMC for detailed dimensions, specifications and lead times.




\* Mounting angles other than 45°, 135°, 225° and 315° are available through the Made to Order (page 630).

Possible to change to the optional mounting angles. For details, refer to page 642, "Procedure for replacing or changing the mounting angle of a pressure gauge".

#### Option/Semi-standard Combinations ©: Combination available : Combination not available A: Available only with NPT thread

	Combination		Option		Semi- standard		Applicable regulator	
Opt	ion/Semi-standard specifications		в	Н	Ν	Z	ARG20(K) to 40(K)	
Option	With bracket	в			Ø	Δ	O	
	With set nut	н			Ø	Δ	Ø	
Semi- standard	Non-relieving type	-N	0	O		Δ	O	
Sel	Name plate and pressure gauge in imperial units (psi)	-Z	Δ	Δ	Δ		Δ	



	Symbol	X2101A	X2101B	X2101C	X2101D			
Mounting angle		45°	135°	225°	315°			
	Mounting angle view		IN Name plate position	IN Name plate position				

O: Combination available : Combination not available

Option/Semi-standard Combinations						vith NPT thread		
	Combination Option/Semi-standard specifications		Option		Semi-standard			Applicable regulator
Opti			В	Н	1	Ν	Z	ARG20(K) to 40(K)
Option	With bracket	в			Ø	Ø	Δ	O
Opt	With set nut	н			Ô	O	Δ	O
, P	0.02 to 0.2 MPa setting	-1	0	0		0	Δ	O
Semi- standard	Non-relieving type	-N	0	0	0		Δ	Ø
sta	Name plate and pressure gauge in imperial units (psi)	-Z	$\square$	$\square$	Δ	Δ		$\triangle$
630			G	SM	С			