# Regulator with Built-in Pressure Gauge Filter Regulator with Built-in Pressure Gauge



# **Transparent bowl guard**

Improved environmental durability due to 2-layer construction

\* Body size 30 or more



# Improved visibility by mounting the pressure gauge on the top of the knob







Installation at higher locations


# Space saving, Labor saving

# Installation height: Approx. 30 mm reduction . For ARG30-B

ARG40-B


Angle adjustment of the pressure gauge makes space saving possible.

AWG20-B



\* Mounting angle can be changed as desired. For details, refer to "Procedure for replacing or changing the mounting angle of a pressure gauge" on page 42.

# No need to machine a hole for the pressure gauge



# Improved operability

Easier limit indicator adjustment due to one-touch mounting/removal of the pressure gauge cover



piping direction



### Pressure gauge anti-revolving mechanism


Pressure gauge does not rotate during knob operation.



# **Transparent bowl guard**

# Better environmental resistance: Transparent bowl guard can protect the inner bowl!

Windows on the bowl guard have been removed and the inner bowl is instead covered with a polycarbonate transparent bowl guard. Now, even if the environment changes and the bowl is exposed to corrosive chemical or oil splash, the foreign matter will not stick directly to the pressurized bowl. This can reduce risk of bowl breakage.



# Better visibility: 360°


Use of transparent bowl guard makes it possible to check the condensate inside the filter bowl and the remaining oil amount in the lubricator from the entire periphery.

# Light weight: Approx. 12% reduction

760 g ← 860 g (For AWG40)

# Modular adapter Easy modular connections for all equipment! Uni 1/8 to 1/2







# **Modular Air Combination** ACG-B Series

### **Series Configuration**


•

Air Combination

ACG20-B

ACG30-B

ACG40-B




•

•

5

•

ACG40A-B



•

•

•

AWG

Lubricator

AL

Air Filter AF	Regulator with Built-in Pressure Gauge <b>ARG</b>
the second se	

•


•

•



Model		Daga			
Model	1/8	1/4	3/8	1/2	Page
ACG20B-B	•	•			
ACG30B-B		•	•		12
ACG40B-B		•	•	•	1

Model		Dogo			
Model	1/8	1/4	3/8	1/2	Page
ACG20C-B	•	•			
ACG30C-B		•	•		14
ACG40C-B		•	•	•	



Model		1 011	3126	
woder	1/8	1/4	3/8	1/2
ACG20D-B		•		
ACG30D-B		•	•	
ACG40D-B		•	•	•

16

# Modular Air Combination **ACG-B** Series

# ACG chment AWG+AFM AF+AFM+ARG AF+ARG AWG+AL AF+ARG+AL

### Air Filter AF

40.9.4	Model
Gat monore (15)	AF20-A
	AF30-A
	AF40-A
a state	
a )	
1 miles	
-	

Model	Port size				
woder	1/8	1/4	3/8	1/2	
AF20-A	•	•			
AF30-A		•	•		
AF40-A		•	•	•	

### Mist Separator AFM

	Model		Port	size	
1988-14-1 996 - 10-1 996 - 10-1	Model	1/8	1/4	3/8	1/2
O'RC HAT & LOD DEC	AFM20-A		•		
10 × 10	AFM30-A		•	•	
	AFM40-A		•	•	•

### Regulator with Built-in Pressure Gauge ARG

Model	1/8	1/4	3/8	1/2	Page
ABG20-B					
AII020-D	•				
ARG30-B		•	•		22
ARG40-B		•	•	•	1

Regulator with Built-in P	ressure Gauge with Backflow	v Function ARG
---------------------------	-----------------------------	----------------

	Model	Port size				Daga
6	Model	1/8	1/4	3/8	1/2	Page
	ARG20K-B					
AND THE PARTY OF T	ARG30K-B		•	•		22
	ARG40K-B		•	•	•	
T						

### Filter Regulator with Built-in Pressure Gauge AWG

AWG40-B

ARG-1614 840 - 100 - 100 - 100

Model		Daga			
woder	1/8	1/4	3/8	1/2	Page
AWG20-B	•				
AWG30-B					32

•

ullet

•




### Lubricator AL



Model	Port size								
woder	1/8	1/4	3/8	1/2					
AL20-A		•							
AL30-A			•						
AL40-A			•						

### Filter Regulator with Built-in Pressure Gauge with Backflow Function AWG□K


	Model		Port size							
	Model	1/8	1/4	3/8	1/2	Page				
	AWG20K-B	•	•							
-	AWG30K-B		•	•		32				
im	AWG40K-B		•	•	•					
9				· · · · · · · · · · · · · · · · · · ·						



	Atta
	<b>ARG</b>

# Air Combination RoHS ACG20-B to ACG40-B





 Semi-standard: Select one each for a to h.
 Option/Attachment/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
 Example) ACG30C-F03DG1-SV1-16NR-B


					<ul> <li>Mounting angle of pressure gauge 0°*1</li> </ul>			
	<u> </u>	<u> </u>		Cumbal	Description		0	
				Symbol	Description	20	Body size	40
					Air filter - Demulator - Lukrianter	20		
				Nil A	Air filter + Regulator + Lubricator Filter regulator + Lubricator	 -		
0		Mo	del combination	B	Air filter + Regulator	 •*2		
9		WIU		C	Air filter + Mist separator + Regulator	 •	•	
				D	Filter regulator + Mist separator	 •	•	
				+		•	•	•
				Nil	Rc	•		
8		Pi	pe thread type	N*3	NPT	•	•	•
			, <b>, ,</b>	<b>F</b> *4	G	•	•	•
				+			1	1]
				01	1/8	•	_	—
			Dort cize	02	1/4	•	•	
4			Port size	03	3/8	_	•	
				04	1/2		_	
				+		 		. <u> </u>
				Nil	Without auto drain	•	•	
6			Option	C*5 D*6	Float type auto drain (N.C.) Float type auto drain (N.O.)	•		
				_	•			
				+		 		
				Nil	Without attachment	•		
				К	Check valve	•		
6		/	Attachment*7	S	Pressure switch	 •		
				V	Pressure relief 3-port valve	•	•	
				V1		•		
				+		 		
		а	Set pressure*8	Nil 1*9	0.05 to 0.85 MPa setting	 •	•	
				+	0.02 to 0.2 MPa setting	•		U
				Nil	Polycarbonate bowl		•	
				2	Metal bowl	 <u> </u>		
				6	Nylon bowl	 •	•	
		b	Bowl <sup>*10</sup>	8	Metal bowl with level gauge	 _	•	
				C	With bowl guard	 •		*11
				6C	With bowl guard (Nylon bowl)	 	*12	*12
	q			+		-	1	1
	Semi-standard			Nil	With drain cock	•		
1	star		Air filter		Drain guide 1/8	•	_	_
	J-i	с	drain port <sup>*13</sup>	<b>J</b> * <sup>14</sup>	Drain guide 1/4	 _	•	•
	Sel			<b>W</b> *15	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_	•	
				+	· · · · · ·			
		Lubricator lubricant			Without drain cock	•		
		a exhaust port			Lubricator with drain cock	•	•	
						 		. <u></u>
			Exhaust	Nil	Relieving type	•	•	
		е	mechanism	N	Non-relieving type	•		
				+				
		f	Flow direction	Nil	Flow direction: Left to right	•	•	
		•		R	Flow direction: Right to left	•		

# Air Combination ACG20-B to ACG40-B Series

<u> </u>							0		
		Symbol		Description			Body size		
						20	30	40	
p		*17 <b>Nil</b> D	ownward			•			
Semi-standard	g ARG	knob*''	lpward			•	•	•	
star		+	•				1		
-		., Nil P	roduct label, caution label for b	bowl, and pressure gauge in SI units:	MPa	•	•		
Se	h Press	sure unit Z <sup>*18</sup> P	roduct label: psi, caution label	for bowl: psi/°F, and pressure gauge:	MPa/psi dual scale	•	•		
MC Prain CG3 appli Prain CG3	when wall mount i guide is NPT1/8 30-B to ACG40-B) cable to the ACG3 guide is G1/8 (a 30-B to ACG40-B)	(applicable to the ACG20-B ). The auto drain port come 30-B to ACG40-B). applicable to the ACG20-E	) and NPT1/4 (applicable to s with a ø3/8" One-touch fi i) and G1/4 (applicable to	standard specifica o the *10 Refer to chemica *11 A bowl guard is *12 A bowl guard is *13 The combination *14 Without a valve f	sure gauge (full-span ( ation. Outlet pressure n al data on page 41 for o provided as standard e provided as standard e o of float type auto drain function o of metal bowl 2 and 8	may increase chemical res equipment (p equipment (n n C and D is	by 0.2 MPa or istance of the l olycarbonate). ylon). not available.	r more. bowl.	
		t in the bowl. Releasing the day is recommended.		efore *16 When choosing with barb fittings		•	ain cock of a lu		
the com the com the com the com the com the comparison of the comp	ne drain cock may or	(0.75 kW, discharge flow is less cur during the start of operatio v for the mounting position o		*18 For pipe thread	els are ACG⊡⊡-B, ACC type: NPT. This produc ent Act. (The SI unit typ	t is for overs	eas use only a	according to the	
the com the com the com the com the com the company of the company	ne drain cock may or to the table below	ccur during the start of operatio	ns. N.C. type is recommended.	*18 For pipe thread	type: NPT. This produc ent Act. (The SI unit typ	et is for overs be is provided	eas use only a	according to the	
the com the comparison of the compar	e drain cock may or to the table below chments cchments	ccur during the start of operatio v for the mounting position of	ns. N.C. type is recommended.	*18 For pipe thread new Measureme	type: NPT. This produc ent Act. (The SI unit typ Fun Prevents backflov	t is for overs e is provided action w from lubri	eas use only a	p. 18	
the com the comparison of the compar	ne drain cock may or to the table below	ccur during the start of operatio v for the mounting position of	ns. N.C. type is recommended.	*18 For pipe thread new Measureme	type: NPT. This produc ent Act. (The SI unit typ Fun	t is for overs e is provided action w from lubri	eas use only a	according to the pan.)	
the com the com the effer	e drain cock may or to the table below chments cchments	ccur during the start of operatio v for the mounting position of e witch	ns. N.C. type is recommended.	*18 For pipe thread new Measureme	type: NPT. This produc ent Act. (The SI unit typ Fun Prevents backflov	et is for overs te is provided tection w from lubri	eas use only a d for use in Jap	p. 18	
the com the com the defer tac he ress to p	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories age 20 for spacer	ccur during the start of operatio v for the mounting position of e witch	ns. N.C. type is recommended.	*18 For pipe thread new Measurements Port size 1/8, 1/4, 3/8	type: NPT. This produc ent Act. (The SI unit typ Fun Prevents backflow Compac Releases residual	et is for overs e is provided action w from lubri ct switch	eas use only a d for use in Jap	p. 18 p. 18	
the com the company of the compan	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories age 20 for spacer	e witch and spacer with bracket. ting position Attachment mounting	ns. N.C. type is recommended.	*18 For pipe thread inew Measurements Port size 1/8, 1/4, 3/8 1/8, 1/4, 3/8, 1/2 Mounting angl Symbol	type: NPT. This produc ent Act. (The SI unit typ Prevents backflow Compace Releases residual Releases residual	et is for overs e is provided action w from lubri ct switch	eas use only a d for use in Jap	p. 18 p. 18	
the com the commentation of the commen	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories age 20 for spacer ment mount Description	e witch and spacer with bracket. ting position Attachment mounting	Applicable mode	*18 For pipe thread new Measureme Port size 1/8, 1/4, 3/8  1/8, 1/4, 3/8, 1/2 Mounting angl	type: NPT. This produc ent Act. (The SI unit typ Fun Prevents backflow Compac Releases residual	et is for overs e is provided action w from lubri ct switch	eas use only a d for use in Jap	p. 18 p. 18	
the com the commentation of the commen	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories age 20 for spacer	e witch and spacer with bracket. ting position Attachment mounting	Applicable mode	*18 For pipe thread inew Measurements Port size 1/8, 1/4, 3/8 1/8, 1/4, 3/8, 1/2 Mounting angle Symbol Gauge angle	type: NPT. This produc ent Act. (The SI unit typ Prevents backflow Compace Releases residual Releases residual	et is for overs e is provided action w from lubri ct switch	eas use only a d for use in Jap	p. 18 p. 18	
the com the commentation of the commen	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories age 20 for spacer ment mount Description Check valve	e witch ort valve and spacer with bracket. ting position Attachment mounting position AF + ARG + K + AL AWG + K + AL AF + ARG + S + AL	Applicable mode ACG20 to 40-B ACG20 to 40-B	*18 For pipe thread inew Measurements Port size 1/8, 1/4, 3/8  1/8, 1/4, 3/8, 1/2  Mounting angle B	type: NPT. This produc ent Act. (The SI unit typ Prevents backflow Compace Releases residual Releases residual	et is for overs e is provided action w from lubri ct switch	eas use only a d for use in Jap	p. 18 p. 18	
the com the com the com the com the com the com the commentation of the commentation o	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories age 20 for spacer ment mount Description	ccur during the start of operation of the mounting position         cort valve         and spacer with bracket.         ting position         Attachment mounting position         AF + ARG + K + AL         AF + ARG + S + AL         AF + S + ARG	Applicable mode ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B	*18 For pipe thread inew Measurements Port size 1/8, 1/4, 3/8  1/8, 1/4, 3/8, 1/2  Mounting angle Symbol Gauge angle B B Mounting angle view	type: NPT. This produc ent Act. (The SI unit typ Prevents backflow Compace Releases residual Releases residual	t is for overs e is provided action w from lubri et switch l pressure ir	eas use only a d for use in Jap	p. 18 p. 18	
the com the commentation of the commen	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories ment mount Description Check valve Pressure	ccur during the start of operation of the mounting position         ort valve         and spacer with bracket.         ting position         Attachment mounting position         AF + ARG + K + AL         AF + ARG + S + AL         AF + AFM + S + ARG         AF + AFM + S + ARG	Applicable mode ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B	*18 For pipe thread inew Measurements Port size 1/8, 1/4, 3/8  1/8, 1/4, 3/8, 1/2  Mounting angle Symbol Gauge angle B B B B B B B B B B B B B B B B B B B	type: NPT. This produc ent Act. (The SI unit typ Prevents backflow Compace Releases residual Releases residual	t is for overs e is provided action w from lubri et switch l pressure ir	eas use only a d for use in Jap	p. 18 p. 18	
the com the commence of the co	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories ment mount Description Check valve Pressure	ccur during the start of operation of the mounting position of the mounting position of the mounting position of the mounting position         cort valve         ort valve         and spacer with bracket.         ting position         Attachment mounting position         AF + ARG + K + AL         AF + ARG + K + AL         AF + ARG + S + AL         AF + S + ARG         AF + ARG + S + AL         AF + ARG + S + ARG         AF + ARG + AL + V	Applicable mode ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B	*18 For pipe thread inew Measurements Port size 1/8, 1/4, 3/8 1/8, 1/4, 3/8, 1/2  Mounting angle Symbol Gauge angle B B B B B B B B B B B B B B B B B B B	type: NPT. This produc ent Act. (The SI unit typ Prevents backflow Compace Releases residual Releases residual	t is for overs e is provided action w from lubri et switch l pressure ir	eas use only a d for use in Jap	p. 18 p. 18	
he res ach nbol x	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories ment mount Description Check valve Pressure	ccur during the start of operation of the mounting position         ort valve         and spacer with bracket.         ting position         Attachment mounting position         AF + ARG + K + AL         AF + ARG + S + AL         AF + AFM + S + ARG         AF + AFM + S + ARG	Applicable mode ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B ACG20 to 40-B	*18 For pipe thread inew Measurements Port size 1/8, 1/4, 3/8  1/8, 1/4, 3/8, 1/2  Mounting angle B B B B B B B B B B B B B B B B B B B	type: NPT. This produc ent Act. (The SI unit typ Prevents backflow Compace Releases residual Releases residual	t is for overs e is provided action w from lubri et switch l pressure ir	eas use only a d for use in Jap	p. 18 p. 18	
he res ach nbol x	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories ment mount Description Check valve Pressure	e witch ort valve and spacer with bracket. ting position Attachment mounting position AF + ARG + K + AL AWG + K + AL AF + S + ARG AF + ARG + S + ARG AF + ARG + S + ARG AF + ARG + AL + V AWG + AL + V AF + ARG + V	Applicable mode ACG20 to 40-B ACG20 to 40-B	*18 For pipe thread inew Measurements Port size       1/8, 1/4, 3/8       1/8, 1/4, 3/8, 1/2       Mounting angle     8     8     8     8     8     8	type: NPT. This produc ent Act. (The SI unit typ Prevents backflow Compace Releases residual Releases residual	t is for overs e is provided action w from lubri et switch l pressure ir	eas use only a d for use in Jap	p. 18 p. 18	
he tac he ress r to p ach mbol K	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories ment mount Description Check valve Pressure switch	e         witch         ort valve         and spacer with bracket.         ting position         Attachment mounting position         AF + ARG + K + AL         AF + ARG + S + ARG         AF + AFM + S + ARG         AF + ARG + AL + V         AF + ARG + V	Applicable mode ACG20 to 40-B ACG20 to 40-B	*18 For pipe thread inew Measurements Port size 1/8, 1/4, 3/8  1/8, 1/4, 3/8, 1/2 Mounting angle B B B B B B B B B B B B B B B B B B	type: NPT. This produc ent Act. (The SI unit typ Prevents backflow Compace Releases residual Releases residual	t is for overs e is provided action w from lubri et switch l pressure ir	eas use only a d for use in Jap	p. 18 p. 18	
f the c rom the Refer tac the ress esse cesse er to p	e drain cock may or to the table below chments eck valv ssure sv ure relief 3-po sories age 20 for spacer ment mount Description Check valve Pressure switch	e witch or the mounting position of witch or tvalve and spacer with bracket. ting position AF + ARG + K + AL AWG + K + AL AF + ARG + S + ARG AF + AFM + S + ARG AF + ARG + AL + V AF + ARG + V AF + ARG + V AF + ARG + V	Applicable mode ACG20 to 40-B ACG20 to 40-B	*18 For pipe thread inew Measurements Port size 1/8, 1/4, 3/8  1/8, 1/4, 3/8, 1/2 Mounting angle B B B B B B B B B B B B B B B B B B	type: NPT. This producent Act. (The SI unit type) Fun Prevents backflow Compace Releases residual	t is for overs be is provided action w from lubri et switch l pressure ir pauge	eas use only a d for use in Jap	p. 18 p. 18	

# Air Combination **Air Filter + Regulator + Lubricator** ACG20-B to ACG40-B





### Standard Specifications

Mc	odel	ACG20-B	ACG30-B	ACG40-B					
	Air filter	AF20-A	AF30-A	AF40-A					
Component	Regulator	ARG20-B	ARG30-B	ARG40-B					
	Lubricator	AL20-A	AL30-A	AL40-A					
Port size		1/8 1/4	1/4 3/8	1/4 3/8 1/2					
Fluid			Air						
Proof pressure	)		1.5 MPa						
Max. operating	pressure		1.0 MPa						
Set pressure ra	ange [ARG]	0.05 to 0.85 MPa							
Ambient and fl	uid temperatures		–5 to 60°C (with no freezing)						
Nominal filtratio	n rating [AF]		5 µm						
Recommended Iu	ubricant [AL]		Class 1 turbine oil (ISO VG32)						
Regulator const	truction [ARG]	Relieving type							
<b>Bowl material</b>	[AF/AL]		Polycarbonate						
Bowl guard	[AF/AL]	Semi-standard (Steel)							
Weight [kg]		0.44	0.89	1.52					

### Attachment/Option Part No.

Section					Attachment/Option part no.	
Sec	Descriptio	on	Model	For ACG20-B	For ACG30-B	For ACG40-B
I	Pressure Standard 0 to 1.0 MPa		0 to 1.0 MPa	GB2-10AS	GB3-10AS	GB4-10AS
	gauge*1	Semi-standard	0 to 0.3 MPa	GB2-3AS	GB3-3AS	GB4-3AS
Option	Float typ	e*2	N.C.	AD27-A	AD37-A	AD47-A
Opl	auto dra	in	N.O.	—	AD38-A	AD48-A
	Spacer	Spacer		Y200-A	Y300-A	Y400-A
	Spacer v	vith brac	ket	Y200T-A	Y300T-A	Y400T-A
Attachment	Check va	alve <sup>*3, *</sup>	4	AKM2000-□01-A (□02-A)	AKM3000-(□01-A) □02-A	AKM4000-(□02-A) □03-A
ach	Pressure	e switch*	×4, *5	IS10M-20-A	IS10M-30-A	IS10M-40-A
Att	Pressure 3-port va			VHS20-□01A □02A	VHS30-⊟02A ⊟03A	□02A VHS40-□03A □04A


\*1 Contact SMC regarding pressure gauge supply for psi unit specifications. \*2 Minimum operating pressure: 0.1 MPa for N.O. type, 0.1 MPa for N.C. type (AD27-A) and 0.15 MPa for N.C. type (AD37-A and AD47-A). Contact SMC for psi and °F specifications.

\*3 For F.R.L. units, port sizes not in ( ) are for standard application. \*4 Separate spacers are required for modular unit.


\*5 Pressure switch cannot be mounted on the inlet and outlet sides of an ARG-B with an upward facing knob (semi-standard specification: -Y).





### Flow Rate Characteristics



### Pressure Characteristics







Condition: Inlet pressure 0.7 MPa

# A Specific Product Precautions

I Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

### Piping

# \land Warning

1. When mounting a check valve, make sure the arrow (IN side) points in the correct direction of air flow.

### Selection

# 🕂 Warning

1. Float type auto drain

Operate under the following conditions to avoid malfunction. <N.O. type>

• Operating compressor: 0.75 kW (100 L/min (ANR)) or more

When using 2 or more auto drains, multiply the value above by the number of auto drains to find the capacity of the compressors you will need.

For example, when using 2 auto drains, 1.5 kW (200 L/min (ANR)) of the compressor capacity is required.

• Operating pressure: 0.1 MPa or more

### <N.C. type>

- Operating pressure for AD27-A: 0.1 MPa or more
- Operating pressure for AD37-A/AD47-A: 0.15 MPa or more
- 2. Use a regulator or filter regulator with a backflow function when mounting a pressure relief 3-port valve on the inlet side to ensure the release of the residual pressure. Otherwise, residual pressure will not be fully released.

Selection

Conditions: Inlet pressure 0.7 MPa, Outlet pressure 0.2 MPa, Flow rate 20 L/min (ANR)

# \land Caution

- 1. If a pressure relief 3-port valve is mounted on the inlet side of the lubricator, causing a backflow of air, it can result in a backflow of oil or damage to internal parts. Do not use it in this manner.
- 2. An F.R.L. unit shipped from the plant has its model number labeled. However, components that are combined together during the distribution process do not have a label on them.

**Air Supply** 

- 1. Use an air filter with 5 um or less filtration rating on the inlet side of the valve to avoid any damage to the seat caused by dust when mounting a pressure relief 3-port valve on the inlet side.

### Mounting/Adjustment

# Caution

Caution

1. When the bowl is installed on the air filter, filter regulator, lubricator, mist separator, or micro mist separator (ACG30-B to ACG40-B), install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.



ACG Attachment || AWG+AFM || AF+AFM+ARG || AF+ARG || AWG+AL || AF+ARG+AL


ARG

AWG

3000

# ACG20-B to ACG40-B Series

### Dimensions




		Semi-standard specifications												
Model		Upwai	rd facing k	knob*2		With auto drain*3	With barb fitting*3	With drain guide*3	Metal bowl*3	Metal bowl with level gauge*3				
	<b>C</b> *4	C <sup>*4</sup> H <sub>2</sub> J K L		В	В	В	В	В						
ACG20-B	87.1	24	33	12	5.5	104.9	—	91.4	87.4	—				
ACG30-B	108.2	35	—	14	7	156.8	123.6	121.9	117.6	137.6				
ACG40-B			186.9	155.6	153.9	149.6	169.6							

\*1 In the case of the ACG20-B's standard specification (downward facing knob), the wall mounting is not possible using the lower side mounting hole on the spacer with a bracket. Use the upper side mounting hole when wall mounting.
\*2 In the case of the vpward facing knob in the semi-standard specification, the C dimension will change. Also, in the case of the ACG20-B, wall mounting is possible by using the lower side mounting hole on the spacer with a bracket.
\*3 For the option/semi-standard specifications (with auto drain, with barb fitting, with drain guide, metal bowl, or metal bowl with level gauge), the total length (B dimension) will vary.
\*4 The length when the regulator knob is unlocked

# Air Combination Filter Regulator + Lubricator ACG20A-B to ACG40A-B





### ACG40A-B

### **Standard Specifications**

Мо	del	ACG20A-B	ACG30A-B	ACG40A-B				
Component	Filter regulator	AWG20-B	AWG30-B	AWG40-B				
Component	Lubricator	AL20-A	AL40-A					
Port size		1/8	1/4	1/4				
Port size		1/4	3/8	3/8 1/2				
Fluid			Air					
Proof pressure			1.5 MPa					
Max. operating	pressure	1.0 MPa						
Set pressure ra	ange [AWG]	0.05 to 0.85 MPa						
Ambient and fl	uid temperatures	–5 to 60°C (with no freezing)						
Nominal filtration	n rating [AWG]		5 µm					
Recommended lu	bricant [AL]		Class 1 turbine oil (ISO VG32)					
Filter regulator cons	struction [AWG]	Relieving type						
Bowl material	[AWG/AL]		Polycarbonate					
Bowl guard	[AWG/AL]	Semi-standard (Steel) Standard (Polycarbonate)						
Weight [kg]		0.39	0.74	1.29				

### Attachment/Option Part No.

Section					Attachment/Option part no.	
Sec	Description Model		Model	For ACG20A-B	For ACG30A-B	For ACG40A-B
Р	Pressure Standard 0 to 1.0 MPa		0 to 1.0 MPa	GB2-10AS	GB3-10AS	GB4-10AS
ga	auge <sup>*1</sup>	Semi-standard	0 to 0.3 MPa	GB2-3AS	GB3-3AS	GB4-3AS
Option	Float typ	e*2	N.C.	AD27-A	AD37-A	AD47-A
<u>g</u>	auto drain N.O.		N.O.	—	AD38-A	AD48-A
	Spacer			Y200-A	Y300-A	Y400-A
te l	Spacer v	with brac	ket	Y200T-A	Y300T-A	Y400T-A
Attachment	Check v	Check valve <sup>*3, *4</sup>		AKM2000-⊡01-A (⊡02-A)	AKM3000-(□01-A) □02-A	AKM4000-(□02-A) □03-A
Atta	Pressure relief 3-port valve* <sup>4</sup>			VHS20-⊡01A ⊡02A	VHS30-⊟02A ⊟03A	□02A VHS40-□03A □04A

\*1 Contact SMC regarding pressure gauge supply for psi unit specifications.

\*2 Minimum operating pressure: 0.1 MPa for N.O. type, 0.1 MPa for N.C. type (AD27-A) and 0.15 MPa for N.C. type (AD37-A and AD47-A). Contact SMC for psi and °F specifications.

\*3 For F.R.L. units, port sizes not in ( ) are for standard application.

\*4 Separate spacers are required for modular unit.


ARG

AWG


# ACG20A-B to ACG40A-B Series

### Dimensions

### ACG20A-B



### ACG30A-B, ACG40A-B



Applicable model		ACG20A-B		ACG30A-B, ACG40A-B									
Optional/Semi-standard specifications	With auto drain	Metal bowl	With drain guide	With auto drain (N.O./N.C.)	Metal bowl Metal bowl with level ga		With drain guide	Drain cock with barb fitting					
Dimensions	M5 x 0.8	B	1/8 Width across flats 14	N.O.: Black N.C.: Gray Thread type/Rc, G: ø10 One-touch fitting Thread type/NPT: ø3/8" One-touch fitting	B	B	1/4 Width across flats 17	Barb fitting applicable tubing: T0604					

			Standard specifications													
Model Port size		•	Б	<b>C</b> *1	P			Р				Bracke	t mount			
		A B	P	C	D		N   P	Е	G	<b>H</b> 1	H2	J	K	L	М	
ACG20A-B	1/8, 1/4	83.2	87.6	92.1	60	2.5	26	41.6	30	24	24	33	12	5.5	3.5	
ACG30A-B	1/4, 3/8	110.2	115.1	108.2	80	2.5	30.5	55.1	41	35	35	—	14	7	4	
ACG40A-B	1/4, 3/8, 1/2	145.2	147.1	114.8	110	0	37.3	72.6	50	40	40	—	18	9	5	


	Semi-standard specifications <sup>*2</sup>											
Model	With auto drain	With barb fitting	With drain guide	Metal bowl with level gauge								
	В	В	В	В	В							
ACG20A-B	104.9	—	91.4	87.4	—							
ACG30A-B	156.8	123.6	121.9	117.6	137.6							
ACG40A-B	186.9	155.6	153.9	149.5	169.5							

\*1 The length when the filter regulator knob is unlocked

\*2 For the option/semi-standard specifications (with auto drain, with barb fitting, with drain guide, metal bowl, or metal bowl with level gauge), the total length (B dimension) will vary.

# Air Combination Air Filter + Regulator ACG20B-B to ACG40B-B





### **Standard Specifications**

Mod	lel	ACG20B-B	ACG30B-B	ACG40B-B				
0	Air filter	AF20-A	AF30-A	AF40-A				
Component	Regulator	ARG20-B	ARG30-B	ARG40-B				
Davit align		1/8	1/4					
Port size		1/4	3/8	3/8 1/2				
Fluid		Air						
Proof pressure			1.5 MPa					
Max. operating	pressure		1.0 MPa					
Set pressure rai	nge [ARG]		0.05 to 0.85 MPa					
Ambient and flu	id temperatures		–5 to 60°C (with no freezing)					
Nominal filtration	rating [AF]		5 µm					
Regulator constr	uction [ARG]		Relieving type					
Bowl material	[AF]		Polycarbonate					
Bowl guard	[AF]	Semi-standard (Steel)	Standard (Po	lycarbonate)				
Weight [kg]		0.32	0.64 1.04					

### Attachment/Option Part No.

Section					Attachment/Option part no.	
Sec	Descriptio	on	Model	For ACG20B-B	For ACG30B-B	For ACG40B-B
	Pressure	Standard	0 to 1.0 MPa	GB2-10AS	GB3-10AS	GB4-10AS
	0 0		0 to 0.3 MPa	GB2-3AS	GB3-3AS	GB4-3AS
Option	Float type*2 N.C.		N.C.	AD27-A AD37-A		AD47-A
ð	auto drain N.C		N.O.	—	AD38-A	AD48-A
	Spacer			Y200-A	Y300-A	Y400-A
jut	Spacer v	vith brac	ket	Y200T-A	Y300T-A	Y400T-A
Ľ۳ –	Pressure	Pressure switch <sup>*3, *4</sup>		IS10M-20-A	IS10M-30-A	IS10M-40-A
Attachment	Pressure 3-port va			VHS20-⊡01A ⊡02A	VHS30-⊡02A ⊡03A	□02A VHS40-□03A □04A


\*1 Contact SMC regarding pressure gauge supply for psi unit specifications.

\*2 Minimum operating pressure: 0.1 MPa for N.O. type, 0.1 MPa for N.C. type (AD27-A) and 0.15 MPa for N.C. type (AD37-A and AD47-A). Contact SMC for psi and °F specifications.
 \*3 Separate spacers are required for modular unit.


4 Pressure switch cannot be mounted on the inlet and outlet sides of an ARG-B with an upward facing knob (semi-standard specification: -Y).

# ACG20B-B to ACG40B-B Series


### Dimensions



### ACG20B-B Semi-standard (-Y) Upward facing knob



### ACG30B-B, ACG40B-B Semi-standard (-Y) Upward facing knob



Applicable mode	el	B-B, ACG40B-E	3					
Optional/Semi-standard specification	With auto drain	ith auto drain Metal bowl With drain guide With auto drain (N.O./N.C.) Metal bowl Metalb				Metal bowl with level gauge	With drain guide	Drain cock with barb fitting
Dimensions	M5 x 0.8	B	1/8 Width across flats 14	N.O.: Black N.C.: Gray Thread type/Rc, G: ø10 One-touch fitting Thread type/NPT: ø3/8" One-touch fitting		B	Vidth across flats 17	Barb fitting applicable tubing: T0604

		Standard specifications													
Model Port size		•	ь	<u> </u>	D	N	N P	Bracket mount							
	AB	В	C	E				G	<b>H</b> 1	H2	J	K	L	М	
ACG20B-B	1/8, 1/4	83.2	87.6	29	25	2.5	28.5	41.6	30	*1	_*1	*1	12*1	5.5 <sup>*1</sup>	3.5
ACG30B-B	1/4, 3/8	110.2	115.1	41	35	2.5	30.5	55.1	41	35	35	—	14	7	4
ACG40B-B	1/4, 3/8, 1/2	145.2	147.1	48	40	0	36.1	72.6	50	40	40	—	18	9	5


		Semi-standard specifications												
Model		U	Jpward fac	ing knob	×2		With auto drain*3	With barb fitting*3	With drain guide*3	Metal bowl*3	Metal bowl with level gauge*3			
	<b>C</b> *4	<b>H</b> 1	H <sub>2</sub>	J	K	L	В	В	В	ВВ				
ACG20B-B	87	24	24	33	12	5.5	104.9	—	91.4	87.4	—			
ACG30B-B	108.5	35	35	—	14	7	156.8	123.6	121.9	117.6	137.6			
ACG40B-B	<b>3</b> 114.5 40 40 — 18 9		186.9	155.6	153.9	149.6	169.6							

1 In the case of the ACG20B-B's standard specification (downward facing knob), the wall mounting is not possible using the lower side mounting hole on the spacer with a bracket. Use the upper side mounting hole when wall mounting.
 2 In the case of the upward facing knob in the semi-standard specification, the C dimension will change. Also, in the case of the ACG20B-B, wall mounting is possible by using the lower side mounting hole on the spacer with a bracket.
 3 For the option/semi-standard specifications (with auto drain, with barb fitting, with drain guide, metal bowl, or metal bowl with level gauge), the total length (B dimension) will vary.
 \*4 The length when the regulator knob is unlocked



# Air Combination Air Filter + Mist Separator + Regulator ACG20C-B to ACG40C-B





### **Standard Specifications**

Mo	odel	ACG20C-B	ACG30C-B	ACG40C-B					
	Air filter	AF20-A	AF30-A	AF40-A					
Component	Mist separator	AFM20-A	ARG30-B         ARG40-B           1/4         1/4           3/8         1/2           Air         1/2           1.5 MPa         1/2           0.05 to 0.85 MPa         0.05 to 0.85 MPa           450         1100           -5 to 60°C (with no freezing)         1100	AFM40-A					
	Regulator	ARG20-B	ARG30-B	ARG40-B					
Port size		1/8 1/4	-	3/8					
Fluid									
Proof pressure	9								
Max. operating	g pressure		1.0 MPa						
Set pressure r	ange [ARG]	0.05 to 0.85 MPa							
Rated flow [L/min	(ANR)]*1 [AFM]	200 450		1100					
Ambient and f	luid temperatures	–5 to 60°C (with no freezing)							
Nominal filtration	on rating [AF/AFM]	AF: 5 μr	n, AFM: 0.3 µm (Filtration efficiency	99.9%)					
Outlet side oil mist co	ncentration [AFM]	Μ	lax.1.0 mg/m <sup>3</sup> (ANR)(≈ 0.8 ppm) <sup>*2, *</sup>	3					
Regulator cons	truction [ARG]		Relieving type						
Bowl material	[AF/AFM]		Polycarbonate						
Bowl guard	[AF/AFM]	Semi-standard (Steel)	Standard (Po	lycarbonate)					
Weight [kg]	_	0.43	0.88	1.52					

\*1 Condition: Mist separator inlet pressure 0.7 MPa. The rated flow varies depending on the inlet pressure. Keep the air flow within the rated flow to prevent an outflow of lubricant to the outlet side.

\*2 At compressor discharge 30 mg/m<sup>3</sup> (ANR)

\*3 Bowl seal and other O-rings are slightly lubricated.

### Attachment/Option Part No.

Section					Attachment/Option part no.					
Sec	Descriptio		For ACG20C-B	For ACG30C-B	For ACG40C-B					
		Standard	0 to 1.0 MPa	GB2-10AS	GB3-10AS	GB4-10AS				
	0 0	-		GB2-3AS	GB3-3AS	GB4-3AS				
Option	Float typ			AD27-A	AD37-A	AD47-A				
Opt	auto dra	in	N.O.		AD38-A A					
	Spacer	Spacer		Y200-A	Y300-A	Y400-A				
) ant				Y200T-A	Y300T-A	Y400T-A				
ا ع	Pressure	switch <sup>∗</sup>	*3, *4	IS10M-20-A	IS10M-30-A	IS10M-40-A				
Attachment	Pressure 3-port va			VHS20-□01A □02A	VHS30-⊡02A ⊡03A	□02A VHS40-□03A □04A				

\*1 Contact SMC regarding pressure gauge supply for psi unit specifications.


\*2 Minimum operating pressure: 0.1 MPa for N.O. type, 0.1 MPa for N.C. type (AD27-A) and 0.15 MPa for N.C. type (AD37-A and AD47-A). Contact SMC for psi and °F specifications.

\*3 Separate spacers are required for modular unit.

\*4 Pressure switch cannot be mounted on the inlet and outlet sides of an ARG-B with an upward facing knob (semi-standard specification: -Y).

# ACG20C-B to ACG40C-B Series

### Dimensions



\*1 In the case of the ACG20C-B's standard specification (downward facing knob), the wall mounting is not possible using the lower side mounting hole on the spacer with a bracket. Use the upper side mounting hole when wall mounting.
 \*2 In the case of the upward facing knob in the semi-standard specification, the C dimension will change. Also, in the case of the ACG20C-B, wall mounting is possible by using the lower side mounting hole on the spacer with a bracket.
 \*3 For the option/semi-standard specifications (with auto drain, with barb fitting, with drain guide, metal bowl, or metal bowl with level gauge), the total length (B dimension) will vary.
 \*4 The length when the regulator knob is unlocked

123.6

155.6

121.9

153.9

117.6

149.6

137.6

169.6

ACG30C-B

ACG40C-B

108.2

114.8

35

40

14

18

7


9

156.8

186.9

# Air Combination Filter Regulator + Mist Separator ACG20D-B to ACG40D-B





### ACG40D-B

### Standard Specifications

Mc	odel	ACG20D-B	ACG30D-B	ACG40D-B						
0	Filter regulator	AWG20-B	AWG30-B	AWG40-B						
Component	Mist separator	AFM20-A	AFM30-A	AFM40-A						
Dert size		1/8	1/4	1/4 3/8						
Port size		1/4	1/4 3/8							
Fluid			1/4 3/8 1/2 Air							
Proof pressure	)	1.5 MPa								
Max. operating	pressure		1.0 MPa							
Set pressure ra	ange [AWG]		0.05 to 0.85 MPa							
Rated flow [L/min	(ANR)]*1 [AFM]	150	330	800						
Ambient and fl	uid temperatures	–5 to 60°C (with no freezing)								
Nominal filtratio	n rating [AWG/AFM]	AWG: 5 μm, AFM: 0.3 μm (Filtration efficiency 99.9%)								
Outlet side oil mist cor	ncentration [AFM]	Μ	ax. 1.0 mg/m <sup>3</sup> (ANR)(≈ 0.8 ppm)* <sup>2,</sup>	*3						
Filter regulator con	struction [AWG]		Relieving type							
<b>Bowl material</b>	[AWG/AFM]		Polycarbonate							
Bowl guard	[AWG/AFM]	Semi-standard (Steel)	Standard (Po	olycarbonate)						
Weight [kg]		0.38	0.73	1.29						

\*1 Condition: Mist separator inlet pressure 0.5 MPa. The rated flow varies depending on the inlet pressure. Keep the air flow within the rated flow to prevent an outflow of lubricant to the outlet side.

\*2 At compressor discharge 30 mg/m<sup>3</sup> (ANR)

\*3 Bowl seal and other O-rings are slightly lubricated.

### Attachment/Option Part No.

Section					Attachment/Option part no.	
Sec	Descriptio	on	Model	For ACG20D-B	For ACG30D-B	For ACG40D-B
		Standard	0 to 1.0 MPa	GB2-10AS	GB3-10AS	GB4-10AS
	gauge*1	Semi-standard	0 to 0.3 MPa	a GB2-3AS GB3-3AS		GB4-3AS
Option	Float type*2N.C.auto drainN.O.		N.C.	AD27-A	AD37-A	AD47-A
opt			N.O.		AD38-A	AD48-A
+	Spacer			Y200-A	Y300-A	Y400-A
len	Spacer v	with brac	ket	Y200T-A	Y300T-A	Y400T-A
Attachment	Pressure 3-port va	Pressure relief 3-port valve <sup>*3</sup>		VHS20-□01A □02A	VHS30-⊟02A ⊟03A	□02A VHS40-□03A □04A

\*1 Contact SMC regarding pressure gauge supply for psi unit specifications. \*2 Minimum operating pressure: 0.1 MPa for N.O. type, 0.1 MPa for N.C. type (AD27-A) and 0.15 MPa for N.C. type (AD37-A and AD47-A). Contact SMC for psi and °F specifications.

\*3 Separate spacers are required for modular unit.


ARG


AWG

# ACG20D-B to ACG40D-B Series


### Dimensions


### ACG20D-B





### ACG30D-B, ACG40D-B





Applicable model		ACG20D-B			ACG30E	-B, ACG40D-E	3		
Optional/Serri-standard specifications	With auto drain	Metal bowl	With drain guide	With auto drain (N.O./N.C.)	Metal bowl	Metal bowl with level gauge With drain guide		Drain cock with barb fitting	
Dimensions	M5 x 0.8	m	1/8 Width across flats 14	N.O.: Black N.C.: Gray Thread type/Rc, G: ø10 One-touch fitting Thread type/NPT: ø3/8" One-touch fitting			Vidth across flats 17	Barb fitting applicable tubing: T0604	

			Standard specifications												
Model	Port size	•	в	<b>C</b> *1	D	D N	N P	Bracket mount							
		AB	P	0				E	G	<b>H</b> 1	H2	J	K	L	M
ACG20D-B	1/8, 1/4	83.2	87.6	92.1	40	2.5	26	41.6	30	24	24	33	12	5.5	3.5
ACG30D-B	1/4, 3/8	110.2	115.1	108.2	50	2.5	30.5	55.1	41	35	35	—	14	7	4
ACG40D-B	1/4, 3/8, 1/2	145.2	147.1	114.8	75	0	37.3	72.6	50	40	40	—	18	9	5


	Semi-standard specifications <sup>*2</sup>								
Model	With auto drain	With barb fitting	With drain guide	Metal bowl	Metal bowl with level gauge				
	В	В	В	В	В				
ACG20D-B	104.9	_	91.4	87.4	—				
ACG30D-B	156.8	123.6	121.9	117.6	137.6				
ACG40D-B	186.9	155.6	153.9	149.5	169.5				

\*1 The length when the filter regulator knob is unlocked \*2 For the option/semi-standard specifications (with auto drain, with barb fitting, with drain guide, metal bowl, or metal bowl with level gauge), the total length (B dimension) will vary. 17

# **Air Combination** ACG-B Series Attachments

### Check Valve: (K) 1/8, 1/4, 3/8

A check valve with intermediate air release port can be easily installed to prevent a backflow of lubricant when redirecting the air flow and releasing the air on the outlet side of the regulator.




ARG

AWG

# ACG-B Series

### Pressure Relief 3-Port Valve: (V)

With the use of a pressure relief 3-port valve, pressure left in the line can be easily exhausted.



\*1 For pipe thread type: NPT only. This product is for overseas use only according to the new Measurement Act. (The SI unit type is provided for use in Japan.)

### **Flow Rate Characteristics**


	Port size		Flow rate characteristics						
Model	IN. OUT	EXH	IN -	→ OUT		$OUT \rightarrow EXH$			
	110, 001		C (dm <sup>3</sup> /s·bar)	b	Cv	C (dm <sup>3</sup> /s·bar)	b	Cv	
VHS20	1/8	1/8	2.4	0.43	0.65	2.5	0.39	0.69	
VH520	1/4	1/0	3.3	0.40	0.88	3.1	0.51	0.84	
VHS30	1/4	1/4	6.4	0.45	1.7	6.2	0.38	1.7	
VH530	3/8	1/4	8.3	0.41	2.3	7.0	0.41	1.9	
	1/4		7.3	0.49	2.0	8.5	0.35	2.3	
VHS40	3/8	3/8	10.9	0.45	3.0	11.6	0.40	3.1	
	1/2	]	14.2	0.39	3.8	13.3	0.43	3.6	

\* Use an air filter on the inlet side for operating protection.

Symbol 2 Pressure relief 3-port valve G Т Е Key can be mounted when residual pressure is released. D С ∡ OUT IN 2 x **P**1 m (Port size) Φ  $\odot$ P<sub>2</sub> İ EXH (Port size)

Model	Standard specifications										
woder	<b>P</b> 1	P2	Α	В	С	D	Е	F	G	Н	I
VHS20	1/8, 1/4	1/8	66.4	22.3	40	37.5	14	46.6	33.6	28	43
VHS30	1/4, 3/8	1/4	80.3	29.4	53	49	19	52	38	30	49
VHS40	1/4, 3/8, 1/2	3/8	104.9	38.5	70	63	22	58	44	36	63


# **ACG-B** Series Accessories (Spacer/Spacer with Bracket)



### **Replacement Parts**

Description	Material	Part no.					
Description	Material	Y200-A	Y300-A	Y400-A			
Seal	HNBR	Y220P-050S	Y320P-050S	Y420P-050S			

### **Spacer with Bracket**



Model	Α	в	С	D	Е	EE	F	G	н	J	к	Applicable model
Y200T-A	3.2	67	29	53.4	24	33	12	5.5	15.5	3.5	30	ACG20⊡-B
Y300T-A	4.2	82	41	71.5	35	—	14	7	19	4	41	ACG30□-B
Y400T-A	5.2	96	48	86.1	40	—	18	9	26	5	50	ACG40□-B

### **Replacement Parts**

Description	Material	Part no.					
Description	Material	Y200T-A	Y300T-A	Y400T-A			
Seal	HNBR	Y220P-050S	Y320P-050S	Y420P-050S			

ACG



Y200-A

Y400-A

Y400T-A

# Modular Type Regulator with Built-in Pressure Gauge **ARG(K)-B Series**

Regulator with Built-in Pressure Gauge ARG(K)-B Series	Model	Port size	Set pressure	Options
	ARG20(K)-B	1/8, 1/4		
	ARG30(K)-B	1/4, 3/8	0.05 to 0.85 MPa 0.02 to 0.2 MPa	Bracket Set nut (for panel mount)
p. 22 to 31	ARG40(K)-B	1/4, 3/8, 1/2	1	

AWG


### Made to Order

2	Special Mounting Angle Specification of Pressure Gauge (-X2101)
1	<b>0.4 MPa Setting (-X406)</b> The maximum set pressure is 0.4 MPa. When a pressure gauge is included, the display will show a range from 0 to 0.7 MPa.




Models with the backflow function include a mechanism which allows for the air pressure in the outlet side to be released to the inlet side.


Example 1) When the pressure in the rear and the front of the cylinder differs:




### Example 2)

When the air supply is cut off and releasing the inlet pressure to the atmosphere, the residual pressure release of the outlet side can be ensured for a safety purpose.







bol: When more than one specification is required, indicate in alphanumeric order. Example) ARG30K-03G1H-1N-B

### Made to order

(Refer to pages 29 and 30 for details.)


	<u> </u>							0	
		-		Symbol	Descri		Body size		
							20	30	40
•				Nil	Without back	flow function		•	•
2	2 With backflow function K <sup>*1</sup> With backflow function				ow function		•	•	
				+					
				Nil	R	c		•	•
8		Pi	be thread type	Ν	NF	т		•	
				F	G	à		•	
				+					
				01	1/			—	
4			Port size	02	1/-			•	•
V	T OIT SIZE			03 3/8					
	04 1/2						—		
				+					
	Option 8	Nil         Without mounting option						•	•
6	a Mounting		<b>B</b> *3	With bracket			•	•	
	0			H	With set nut (for panel mount)		•		
	1			+					
				G1	0°		•	•	•
6		b	Mounting angle of	G2	90°	Mounting angle view:	•	•	•
			pressure gauge*4	G3	180°	Refer to the next page	•	•	•
				G4 +	270°			•	
				+ Nil	0.05 to 0.05 MDs sotting				
		с	Set pressure <sup>*5</sup>	1 NII	0.05 to 0.85 MPa setting 0.02 to 0.2 MPa setting			•	•
				+	0.02 to 0.2 MPa Setting			•	
	σ		Exhaust	Nil	Relieving type			•	
	dan	d	mechanism	N	Non-relieving type				
7	d Exhaust Mil Relieving type mechanism N Non-relieving type + e Knob Nil Downward Y Upward							•	-
•			Nil	Downward			•	•	
	Ser	е	Knob	Y	Upward			•	•
		+						•	
			Droopure	Nil	Product label and pressure gaug	je in SI units: MPa		•	
		f	Pressure unit	<b>Z</b> *6	Product label: psi, Pressure gaug		O*7	0*7	0*7

# Regulator with Built-in Pressure Gauge ARG20-B to ARG40-B Series Regulator with Built-in Pressure Gauge with Backflow Function ARG20K-B to ARG40K-B Series



ARG40-B, ARG40K-B

### Mounting angle of pressure gauge



\*1 Set the inlet pressure to at least 0.05 MPa higher than the set pressure.

\*2 Options B and H are not assembled and supplied loose at the time of shipment.

\*3 Assembly of a bracket and set nuts

\*4 When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.85 MPa) type. 0.3 MPa pressure gauge for 0.2 MPa type. Mounting angles other than the above (45°, 135°, 225°, and 315°) are available through the made to order (page 30).

Possible to change to the optional mounting angles. For details, refer to page 42, "Procedure for replacing or changing the mounting angle of a pressure gauge."

- \*5 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.
- \*6 For pipe thread type: NPT
  - This product is for overseas use only according to the new Measurement Act. (The SI unit type is provided for use in Japan.)
- \*7 O: For pipe thread type: NPT only

### **Standard Specifications**

Model	ARG20(K)-B	ARG30(K)-B	ARG40(K)-B		
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2		
Fluid	Air				
Ambient and fluid temperatures	–5 to 60°C (with no freezing)				
Proof pressure	1.5 MPa				
Max. operating pressure	1.0 MPa				
Set pressure range		0.05 to 0.85 MPa			
Construction	Relieving type				
Weight [kg]	0.21	0.40	0.57		

### **Option/Part No.**


	Ontional anoait	inationa	Model				
	Optional specif	Ications	ARG20(K)-B	ARG30(K)-B	ARG40(K)-B		
Bracket assembly			ARG23P-270AS	ARG33P-270AS	ARG43P-270AS		
Set nut			ARG23P-260S	P-260S ARG33P-260S A			
	Standard	1.0 MPa	GB2-10AS	GB3-10AS	GB4-10AS		
Pressure		0.3 MPa	GB2-3AS	GB3-3AS	GB4-3AS		
gauge	Semi-standard	1.0 MPa/150 psi	GB2-10AS-X101	GB3-10AS-X101	GB4-10AS-X101		
		0.3 MPa/45 psi	GB2-3AS-X101	GB3-3AS-X101	GB4-3AS-X101		

# ARG20-B to ARG40-B Series ARG20K-B to ARG40K-B Series


### Flow Rate Characteristics (Representative values)

Condition: Inlet pressure of 0.7 MPa

Conditions: Inlet pressure of 0.7 MPa, Outlet pressure of 0.2 MPa, Flow rate 20 L/min (ANR)




### Pressure Characteristics (Representative values)



# Regulator with Built-in Pressure Gauge ARG20-B to ARG40-B Series Regulator with Built-in Pressure Gauge with Backflow Function ARG20K-B to ARG40K-B Series

### Construction



No.	Description	Material		Faitilo.						
INO.	Description	Material	ARG20(K)-B	ARG30(K)-B	ARG40(K)-B					
4	Valve	Brass, HNBR	AR20P-410S	AR30P-410S	AR40P-410S					
5	Diaphragm assembly	Weatherable NBR	AR20P-150AS	AR30P-150AS	AR40P-150AS					
6	Valve guide assembly	POM/NBR	AR20P-050AS	AR30P-050AS	AR40P-050AS					
7	Pressure gauge <sup>*1</sup>	—	GB2-10AS	GB3-10AS	GB4-10AS					
8	Pressure gauge cover	PC	ARG20P-400S	ARG30P-400S	ARG40P-400S					
9	Clip	Stainless steel	ARG20P-420S	ARG30P-420S	ARG40P-420S					
10	Check valve assembly*2	—	AR23KP-020AS							


\*1 Only the standard part numbers are listed in the pressure gauges. For the optional part numbers, refer to page 24.


\*2 Check valve assembly is applicable for a filter regulator with backflow function (ARG20K-B to ARG40K-B) only. Assembly of a check valve cover, check valve body assembly and 2 mounting screws



# ARG20-B to ARG40-B Series ARG20K-B to ARG40K-B Series

### Working Principle (Regulator with Built-in Pressure Gauge with Backflow Function)







When the inlet pressure is higher than the regulating pressure, the check valve ② closes and operates as a normal regulator (Figure 1). When the inlet pressure is shut off and released, the check valve ③ opens and the pressure in the diaphragm chamber ① is released into the inlet side (Figure 2).

This lowers the pressure in the diaphragm chamber ① and the force generated by the spring ③ lifts the diaphragm. The valve ④ opens through the stem, and the outlet pressure is released to the inlet side (Figure 2).


# Regulator with Built-in Pressure Gauge ARG20-B to ARG40-B Series Regulator with Built-in Pressure Gauge with Backflow Function ARG20K-B to ARG40K-B Series

### Dimensions





Panel mounting dimensions






Plate thickness ARG20(K)-B to ARG40(K)-B: Max. 3.5

Model	Standard specifications										
Model	<b>P</b> 1	Α	<b>B</b> *1	С	D	F	J	AA	AB	AC	
ARG20(K)-B	1/8, 1/4	40	87.1	26.5	28.5	M39 x 1.5	28.5	ø37	45	46.5	
ARG30(K)-B	1/4, 3/8	53	108.2	30.7	29.4	M50 x 1.5	29.4	ø47	58	58.8	
ARG40(K)-B	1/4, 3/8, 1/2	70	114.8	35.8	33.8	M55 x 1.5	33.8	ø52	70	70	

						Optional sp	ecifications	3				
Model	Bracket mount								Panel mount			
	М	N	Q	R	S	т	U	V	W	X	Y	Z
ARG20(K)-B	35	48	60	5.4	10.4	65	2.3	37.7	39.5	52.5	19.5	6
ARG30(K)-B	45	58.5	70	6.5	10.5	75	2.3	50.1	50.5	65	25	7
ARG40(K)-B	50	65.5	75.2	8.5	12.5	85	2.3	53.7	55.5	70	27.5	7

\*1 The dimension of B is the length when the regulator knob is unlocked.

Regulator with Built-in Pressure Gauge/ARG20-B to ARG40-B Regulator with Built-in Pressure Gauge with Backflow Function/ARG20K-B to ARG40K-B

# Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.



### 1 0.4 MPa Setting

The setting specification is 0.4 MPa. The display will show a range from 0 to 0.7 MPa.

### Specifications

Proof pressure [MPa]	1.5			
Max. operating pressure [MPa]	1.0			
Set pressure range [MPa]*1	0.05 to 0.4			

\*1 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

### Applicable Model


Model	ARG20(K)-B	ARG30(K)-B	ARG40(K)-B	
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	
ARG[	30 K-	<b>0</b> 3	G1-[	- B - <u>X406</u> ● • 0.4 MPa setting

• Option/Pressure gauge/Semi-standard: Select one each for a to e.

 Option/Pressure gauge/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) ARG30K-03G1H-NY-B-X406

/	<u> </u>	<u> </u>	<u> </u>	Symbol	Desci	intion		0	
				Symbol	Desci	iption		Body size	40
							20	30	40
0		\\/i+b	backflow function	Nil	Without back	flow function		•	•
0				<b>K</b> *2	With backfl	ow function	•		•
				+					
_				Nil	R			•	•
8		P	ipe thread type	N	NF			•	•
				F		<u>à</u>		•	•
				+					
				01	1/		•	—	
			Port size	02	1/		•	•	•
J				03	3/		•	•	
		04 1/2					—		•
				+					
~	*3 K			Nil	Without mounting option			•	•
5	Option &	а	Mounting	<b>B</b> *4	With bracket	•	•	•	
	0			H	With set nut (for panel mount)				•
	1			+	00			-	-
				G1	0°	<b>.</b>	•	•	•
6		b	Mounting angle of	G2	90° 180°	Mounting angle view:		•	•
Ū			pressure gauge*5	G3		Refer to the figure below			•
	J			G4 +	270°				U
				+ Nil	Relieving type			•	
		с	Exhaust mechanism	N	Non-relieving type				
	Semi-standard			<u>  N</u> +					•
_	pu			Nil	Downward			•	
7	-sta	d	Knob	Y	Upward				
	i a			+	opilaid		<b>—</b>	<b>└</b>	-
	Se			Nil	Product label and pressure gauge in	SLunits: MPa		•	•
		е	Pressure unit	<b>Z</b> *6	Product label: psi, Pressure gauge: N		*7	O*7	0*7

### Mounting angle of pressure gauge



\*2 Set the inlet pressure to at least 0.05 MPa higher than the set pressure.

\*3 Options B and H are not assembled and supplied loose at the time of shipment.

\*4 Assembly of a bracket and set nuts
\*5 A 0.7 MPa pressure gauge will be fitted.

Mounting angles other than the above (45°, 135°, 225°, and 315°) are available through the made to order (page 30).

Possible to change to the optional mounting angles. For details, refer to page 42, "Procedure for replacing or changing the mounting angle of a pressure gauge."

\*6 For pipe thread type: NPT. This product is for overseas use only according to the new Measurement Act. (The SI unit type is provided for use in Japan.)


\*7 O: For pipe thread type: NPT only



# Regulator with Built-in Pressure Gauge ARG20-B to ARG40-B Series Regulator with Built-in Pressure Gauge with Backflow Function ARG20K-B to ARG40K-B Series

Moc Moc Port s	lel	le Model ARG20(K)-B 1/8, 1/4		0(K)-B ARG40(K)-B , 3/8 1/4, 3/8, 1/2					ACG
Option Option/	n/Sem /Press	i-standard: Select one ure gauge G5/Semi-stand G30K-03G5H-1N-B-X2	each for a lard symbol	<b>b G G G G G G G G G G</b>	• Mounti Symbo A B C D		of pressure gauge lescription 45° 135° 225° 315° ble below.		AWG + AL AF + ARG + AL
<u> </u>	<u> </u>		Symbol	Description		20	Body size 30	40	AF + ARG
3	With	backflow function	Nil K*1	Without backflow function With backflow function		•	•	•	1
	P	ipe thread type	+ Nil N F + 01 02	Rc NPT G 1/8 1/4		• • • •	•     •     •     •     •     •     •	• • • •	AF + AFM + ARG
		1 011 3126	03 04 +	<u>3/8</u> 1/2		_	• -	•	L
Option <sub>5*</sub>	а	Mounting		Without mounting option With bracket With set nut (for panel mount)		•	•	•	AWG+AFM
	b	Set pressure*4	Nil 1	0.05 to 0.85 MPa setting 0.02 to 0.2 MPa setting		•	•	•	jut
Semi-standard	c	Exhaust mechanism	+ Nil N +	Relieving type Non-relieving type		•	•	•	Attachment
Semi-sta	d	Knob	Nil Y	Downward Upward		•	•	•	Att
	е	Pressure unit	+ Nil Z*5	Product label and pressure gauge in SI units: MPa Product label: psi, Pressure gauge: MPa/psi dual scale		● ○*6	● ○*6	● ○*6	RG

### Mounting angle of pressure gauge



\*1 Set the inlet pressure to at least 0.05 MPa higher than the set pressure.

\*2 Options B and H are not assembled and supplied loose at the time of shipment.
 \*3 Assembly of a bracket and set nuts

\*4 When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.85 MPa) type. 0.3 MPa pressure gauge for 0.2 MPa type. \*5 For pipe thread type: NPT. This product is for overseas use only according to the new Measurement Act. (The SI unit type is provided for use in Japan.)
\*6 ○: For pipe thread type: NPT only

AWG



# **ARG Series** Specific Product Precautions

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

Selection

# **M**Warning

1. Residual pressure disposal (outlet pressure removal) is not possible for the ARG20-B to ARG40-B even though the inlet pressure is exhausted. When the residual pressure disposal is performed, use the regulator with backflow function (ARG20K-B to ARG40K-B).

Maintenance

# **M**Warning

1. When using the regulator with backflow function between a solenoid valve and an actuator, check the pressure gauge periodically.

Sudden pressure fluctuations may shorten the durability of the pressure gauge.

### Mounting/Adjustment

# **M**Warning

- 1. Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- 2. Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

# **A**Caution

- 1. Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
  - Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
  - Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).



# Modular Type Filter Regulator with Built-in Pressure Gauge **AVVG(K)-B Series**


Filter Regulator with Built-in Pressure Gauge AWG(K)-B Series	Model	Port size	Set pressure	Options
	AWG20(K)-B	1/8, 1/4		
	AWG30(K)-B	1/4, 3/8	0.05 to 0.85 MPa 0.02 to 0.2 MPa	Bracket Set nut (for panel mount) Float type auto drain
p. 32 to 41	AWG40(K)-B	1/4, 3/8, 1/2		

ACG


### Made to Order


0.4 MPa Setting (-X406)
 The maximum set pressure is 0.4 MPa. When a pressure gauge is included, the display will show a range from 0 to 0.7 MPa.





Example) When the air supply is cut off and releasing the inlet pressure to the atmosphere, the residual pressure release of the outlet side can be ensured for a safety purpose.





(Refer to page 40 for details.)

	<u> </u>							0			
				Symbol	Descr	ription		Body size			
							20	30	40		
				Nil	Without back	flow function					
2		With	backflow function	<b>K</b> *1	With backfl		•	•	•		
				+				_	_		
				Nil	R	lc	●	•			
8		Pi	pe thread type	N*2	NF	РТ	•	•			
				<b>F</b> *3	0	6	•				
				+							
				01	1/	/8	•				
4			Port size	02	1/4			•	•		
U	Port size			03	3/			•	•		
				04	1/	—	—				
				+							
				Nil	Without mounting option		•	•			
	*4	a Mounting		<b>B</b> *5	With bracket		•	•			
_	UC			н	With set nut (for panel mount)						
6	Option :	ž						1			
	0		Float type	Nil	Without auto drain		•	•			
		b	auto drain	<b>C</b> *6		closed when pressure is not applied.	•				
				<b>D</b> *7	N.O. (Normally open) Drain port is o	pen when pressure is not applied.	_				
	1			+				-			
				G1	0°		•	•			
6		с	с		Mounting angle of	G2	90°	Mounting angle view:	•	•	
			pressure gauge*8	G3	180°	Refer to the next page	•	•	•		
				G4	270°		•				
				+			-	•	•		
		d	Set pressure <sup>*9</sup>	Nil	0.05 to 0.85 MPa setting		•	•	•		
				<u>1</u> +	0.02 to 0.2 MPa setting						
				+ Nil	Polycarbonate bowl	]					
				2	Metal bowl		•	•			
	ard			6	Nylon bowl		•	•	-		
	nda	е	Bowl <sup>*10</sup>	8	Metal bowl with level gauge		•	•	•		
0	sta			C	With bowl guard		•	*11	*11		
	e Bowl			6C	With bowl guard (Nylon bowl)						
				+			•				
				Nil	With drain cock			•			
					Drain guide 1/8		•				
		f	Drain port <sup>*13</sup>	<b>J</b> * <sup>14</sup>	Drain guide 1/4		_	•			
				<b>W</b> *15	Drain cock with barb fitting			•			
								- <b>-</b>	-		

# Filter Regulator with Built-in Pressure Gauge AWG20-B to AWG40-B Series Filter Regulator with Built-in Pressure Gauge with Backflow Function AWG20K-B to AWG40K-B Series




ACG



							0		
				Symbol	Description	Body size			
				20	30	40			
	Ird	-	Exhaust	Nil	Relieving type	•			
	nda	g	mechanism	Ν	Non-relieving type	•	•		
0	standard			+					
	Semi-	h	Pressure unit	Nil	Product label, caution label for bowl, and pressure gauge in SI units: MPa	•			
	Se		Fressure unit	<b>Z</b> *16	Product label: psi, Caution label for bowl: psi/°F, Pressure gauge: MPa/psi dual scale	O*17	O*17	O*17	

### Mounting angle of pressure gauge



\*1 Set the inlet pressure to at least 0.05 MPa higher than the set pressure.

- \*2 Drain guide is NPT1/8 (applicable to the AWG20(K)-B) and NPT1/4 (applicable to the AWG30(K)-B to AWG40(K)-B). The auto drain port comes with a ø3/8" One-touch fitting (applicable to the AWG30(K)-B to AWG40(K)-B).
- \*3 Drain guide is G1/8 (applicable to the AWG20(K)-B) and G1/4 (applicable to the AWG30(K)-B to AWG40(K)-B).
- \*4 Options B and H are not assembled and supplied loose at the time of shipment.
- \*5 Assembly of a bracket and set nuts
- \*6 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in

the bowl. Releasing the residual condensate before ending operations for the day is recommended.

- \*7 If the compressor is small (0.75 kW, discharge flow is less than 100 L/min (ANR)), air leakage from the drain cock may occur during the start of operations. N.C. type is recommended.
- \*8 When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.85 MPa) type. 0.3 MPa pressure gauge for 0.2 MPa type. Possible to change to the optional mounting angles. For details, refer to page 42, "Procedure for replacing
- or changing the mounting angle of a pressure gauge." \*9 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

**SMC** 

- \*10 Refer to chemical data on page 41 for chemical resistance of the bowl.
- \*11 A bowl guard is provided as standard equipment (polycarbonate).
- \*12 A bowl guard is provided as standard equipment (nylon).
- \*13 The combination of float type auto drain C and D is not available.
- \*14 Without a valve function
- \*15 The combination of metal bowl 2 and 8 is not available.\*16 For pipe thread type: NPT. This product is for
- overseas use only according to the new Measurement Act. (The SI unit type is provided for use in Japan.)
- \*17 O: For pipe thread type: NPT only

### Standard Specifications

Model	AWG20(K)-B	AWG30(K)-B	AWG40(K)-B			
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2			
Fluid		Air				
Ambient and fluid temperatures	–5 to	60°C (with no free	ezing)			
Proof pressure	1.5 MPa					
Max. operating pressure	1.0 MPa					
Set pressure range		0.05 to 0.85 MPa				
Nominal filtration rating		5 µm				
Drain capacity [cm <sup>3</sup> ]	8	25	45			
Bowl material		Polycarbonate				
Bowl guard	Semi-standard (Steel)	Standard (Po	olycarbonate)			
Construction	Relieving type					
Weight [kg]	0.26	0.46	0.76			

# AWG20-B to AWG40-B Series AWG20K-B to AWG40K-B Series

### **Option/Part No.**

	Ontional aposit	inationa		Model	
	Optional specif	ICATIONS	AWG20(K)-B	AWG30(K)-B	AWG40(K)-B
Bracket a	assembly		ARG23P-270AS	ARG33P-270AS	ARG43P-270AS
Set nut			ARG23P-260S	ARG23P-260S ARG33P-260S	
	Standard	1.0 MPa	GB2-10AS	GB3-10AS	GB4-10AS
Pressure		0.3 MPa	GB2-3AS	GB3-3AS	GB4-3AS
gauge	Semi-standard	1.0 MPa/150 psi	GB2-10AS-X101	GB3-10AS-X101	GB4-10AS-X101
		0.3 MPa/45 psi	GB2-3AS-X101	GB3-3AS-X101	GB4-3AS-X101

### Bowl Assembly/Part No.

David	Drain				Model	
Bowl material	discharge mechanism	Drain port	Other	AWG20(K)-B	AWG30(K)-B	AWG40(K)-B
		With drain cock	—	C2SF-A	—	_
		With drain cock	With bowl guard	C2SF-C-A	C3SF-A	C4SF-A
	Manual	Drain cock with barb fitting	With bowl guard	—	C3SF-W-A	C4SF-W-A
Delveerbenete		With drain guide	—	C2SF□-J-A	—	_
Polycarbonate		(without valve function)	With bowl guard	C2SF□-CJ-A	C3SF□-J-A	C4SF□-J-A
	Automatic*1	Normally closed (N.C.)	—	AD27-A	—	—
	(Automatic (Auto drain)	Normally closed (N.C.)	With bowl guard	AD27-C-A	AD37□-A	AD47□-A
	(Auto drain)	Normally open (N.O.)	With bowl guard	—	AD38□-A	AD48□-A
	Manual	With drain cock	—	C2SF-6-A	—	—
		With drain cock	With bowl guard	C2SF-6C-A	C3SF-6-A	C4SF-6-A
		Drain cock with barb fitting	With bowl guard	_	C3SF-6W-A	C4SF-6W-A
Nulan		With drain guide	—	C2SF□-6J-A	—	_
Nylon		(without valve function)	With bowl guard	C2SF□-6CJ-A	C3SF□-6J-A	C4SF⊡-6J-A
	Automatic*1		—	AD27-6-A	—	—
	(Automatic (Auto drain)	Normally closed (N.C.)	With bowl guard	AD27-6C-A	AD37□-6-A	AD47□-6-A
	(Auto urain)	Normally open (N.O.)	With bowl guard	—	AD38□-6-A	AD48□-6-A
		With drain cock	—	C2SF-2-A	C3SF-2-A	C4SF-2-A
	Manual	With drain cock	With level gauge	—	C3LF-8-A	C4LF-8-A
	Manual	With drain guide	—	C2SF□-2J-A	C3SF⊡-2J-A	C4SF⊡-2J-A
Metal		(without valve function)	With level gauge	_	C3LF⊡-8J-A	C4LF□-8J-A
ivietal		Normally along (N.C.)		AD27-2-A	AD37□-2-A	AD47□-2-A
	Automatic*1	Normally closed (N.C.)	With level gauge	_	AD37□-8-A	AD47□-8-A
	(Auto drain)	Normally open (N.O.)			AD38□-2-A	AD48□-2-A
			With level gauge		AD38□-8-A	AD48□-8-A

\*1 Minimum operating pressure: N.O. type-0.1 MPa (AD38-A, AD48-A); N.C. type-0.1 MPa (AD27-A) and 0.15 MPa (AD37-A, AD47-A).


Bowl assembly comes with a bowl seal.

 $\Box$  in bowl assembly part numbers indicates a pipe thread type (applicable tubing for auto drain).

No indication is necessary for Rc thread; however, indicate N for NPT thread, and F for G thread. (For auto drain, Nil: ø10, N: ø3/8")

Please consult with SMC separately for psi and  $^\circ\text{F}$  unit display specifications.

# Filter Regulator with Built-in Pressure Gauge AWG20-B to AWG40-B Series Filter Regulator with Built-in Pressure Gauge with Backflow Function AWG20K-B to AWG40K-B Series



0.4 0.5 0.6 0.7 0.8 0.9

Inlet pressure [MPa]

0.4 0.5 0.6 0.7 0.8

Inlet pressure [MPa]

0.9

ARG


0.4 0.5 0.6 0.7 0.8

Inlet pressure [MPa]

0.9 1

# AWG20-B to AWG40-B Series AWG20K-B to AWG40K-B Series

### Construction




### AWG20K-B to AWG40K-B


(Filter Regulator with Built-in Pressure Gauge with Backflow Function)

### **Component Parts**

Description	Material	Color		
Body	ADC	White		
Bonnet	PBT	White		
Knob	POM	Gray		
	Description Body Bonnet	Description         Material           Body         ADC           Bonnet         PBT		



Drain



### **Replacement Parts**

Nia	Description	Material	Part no.						
No.	D. Description	Material	AWG20(K)-B	AWG30(K)-B	AWG40(K)-B				
4	Valve assembly	Brass, HNBR	AW20P-340AS	AW30P-340AS	AW40P-340AS				
5	Element	Non-woven fabric	AF20P-060S	AF30P-060S	AF40P-060S				
6	Diaphragm assembly	Weatherable NBR	AR20P-150AS	AR30P-150AS	AR40P-150AS				
7	Bowl seal	NBR	C2SFP-260S	C32FP-260S	C42FP-260S				
8	Bowl assembly <sup>*1</sup>	PC	C2SF-A	C3SF-A*2	C4SF-A*2				
9	Pressure gauge*3	_	GB2-10AS	GB3-10AS	GB4-10AS				
10	Pressure gauge cover	PC	ARG20P-400S	ARG30P-400S	ARG40P-400S				
11	Clip	Stainless steel	ARG20P-420S	ARG30P-420S	ARG40P-420S				
12	Check valve assembly <sup>*4</sup>	_		AR23KP-020AS					

\*1 Bowl assembly comes with a bowl seal. Please consult with SMC separately for psi and °F unit display specifications.
\*2 Bowl assembly for the AWG30(K)-B and AWG40(K)-B models comes with a bowl guard (Material: Polycarbonate).

\*3 Only the standard part numbers are listed in the pressure gauges. For the optional part numbers, refer to page 35.


\*4 Check valve assembly is applicable for a filter regulator with backflow function (AWG20K-B to AWG40K-B) only.

Assembly of a check valve cover, check valve body assembly and 2 mounting screws

# Filter Regulator with Built-in Pressure Gauge AWG20-B to AWG40-B Series Filter Regulator with Built-in Pressure Gauge with Backflow Function AWG20K-B to AWG40K-B Series

### Working Principle (Filter Regulator with Built-in Pressure Gauge with Backflow Function)

### AWG20K-B to AWG40K-B



When the inlet pressure is higher than the regulating pressure, the check valve ② closes and operates as a normal regulator (Figure 1). When the inlet pressure is shut off and released, the check valve ③ opens and the pressure in the diaphragm chamber ① is released into the inlet side (Figure 2).


This lowers the pressure in the diaphragm chamber ① and the force generated by the spring ③ lifts the diaphragm. The value ④ opens through the stem, and the outlet pressure is released to the inlet side (Figure 2).

ACG

Attachment || AWG+AFM || AF+AFM+ARG || AF+ARG || AWG+AL || AF+ARG+AL

# AWG20-B to AWG40-B Series AWG20K-B to AWG40K-B Series

### Dimensions



Model Standard specifications												
woder	<b>P</b> 1	Α	В	<b>C</b> *1	D	E	F	G	J	AA	AB	AC
AWG20(K)-B	1/8, 1/4	40	87.6	92.1	26	_	M39 x 1.5	40	26	ø37	45	46.5
AWG30(K)-B	1/4, 3/8	53	115.1	108.2	29.4	30	M50 x 1.5	55	29.4	ø47	58	58.8
AWG40(K)-B	1/4, 3/8, 1/2	70	147.1	114.8	37.3	38.4	M55 x 1.5	80	37.3	ø52	70	70

	Optional specifications							Semi-standard specifications											
Model			Brac	ket m	ount				Panel mount			With auto drain	With barb fitting	With drain guide	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide	
	M	N	Q	R	S	Т	U	V	W	X	Υ	Ζ	В	В	В	В	B	B	В
AWG20(K)-B	35	48	65	5.4	10.4	65	2.3	42.7	39.5	52.5	19.5	6	104.9	—	91.4	87.4	93.9	_	—
AWG30(K)-B	45	58.5	70	6.5	10.5	75	2.3	50.1	50.5	65	25	7	156.8	123.6	121.9	117.6	122.1	137.6	142.1
AWG40(K)-B	50	65.5	75.2	8.5	12.5	85	2.3	53.7	55.5	70	27.5	7	186.9	155.6	153.9	149.5	154	169.5	174

\*1 The length when the filter regulator knob is unlocked



Filter Regulator with Built-in Pressure Gauge/AWG20-B to AWG40-B Filter Regulator with Built-in Pressure Gauge with Backflow Function/AWG20K-B to AWG40K-B

# Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.



Γ

	-		is 0.4 N	IPa. The display will sho	-					
		ations				Applicable				
Proof pressure [MPa] 1.5 Max. operating pressure [MPa] 1.0					Model	AWG20(K)		<u>30(К)-В</u>	AWG40(K)-B	
		ting pressure [ re range [MPa]		1.0 0.05 to 0.4		Port size	1/8, 1/4	1/4	, 3/8	1/4, 3/8, 1/2
				pecification pressure in some ca	see but use					
		ithin the specifica			1303, but use					
						1				( <b>a</b> ) ) ) ) )
١V	VG	i 30∥I	K  -	03     G	1 -	- <b>B</b> -)	X406		essure ga e each for a	uge/Semi-standard:
								<ul> <li>Option/Pressure</li> </ul>	e gauge/Semi-sta	andard symbol: When more than
		6 (	2	6 6 6 (	6 0	0.4 MPa se	tting			icate in alphanumeric order. 3G1H-2N-B-X406
		•					etting •	Example) A		
/	_	-					0			
			Symbol	Descr	ription		Body size			
						2	0 30 4	0		
			Nil	Without back	flow function			•		
) w	/ith ba	ckflow function	<b>K</b> *2	With backfl				•		
			+							
	D:	thread to a	Nil N*3							
	Pipe	thread type	F*4	NF	3					
			+							
		-	01	1,	/8		) —   -	-		
Port size		02		/4			Ð			
1			03		/8	_=				
			04 +	1/	12		-   -   •			
			Nil	Without mounting option						
a Mounting		<b>B</b> *6	With bracket				Ð			
, lo			H	With set nut (for panel moun	nt)			D		
Option 5*	•		+ Nil	Without auto drain						
ľ	b	Float type	C*7	N.C. (Normally closed) Drain port is	closed when pressure is r					
		auto drain	<b>D</b> *8	N.O. (Normally open) Drain port is o			- •			
_			+							
			G1	0°						
	с	Mounting angle of pressure gauge*9	G2 G3	90° 180°	Mounting angle Refer to the figure or					of Pressure Gauge
		pressure gauge	G4	270°				Symbol	Gauge angle	Mounting angle view
			+		1					
			Nil	Polycarbonate bowl				<b>G</b> 1	<b>0</b> °	
			2	Metal bowl						MP3/
	d	Bowl*10	6	Nylon bowl						CHE CO
			8 C	Metal bowl with level gauge				*11		
			6C	With bowl guard With bowl guard (Nylon bow	4)			*12 G2	90°	
2			+	- Than bown guard (Hylon bow	9					
Semi-standard			Nil	With drain cock						CELES CON
-sta	e	Drain port*13	<b>J</b> *14	Drain guide 1/8				- 6		
B		port	<b>W</b> *15	Drain guide 1/4				G3	180°	
ů			₩ <sup>*15</sup>	Drain cock with barb fitting			-   •   (			
		Exhaust	Nil	Relieving type						i i i i i i i i i i i i i i i i i i i
	f	mechanism	N	Non-relieving type						
			+					G4	270°	
			Nil	Product label, caution label for bowl, and p	resource gourse in Clumiter MD	a 🛛 🖉			-	

\*3 urain guide is NPT11/8 (applicable to the AWG20(K)-B) and NPT1/4 (applicable to the AWG30(K)-B to AWG40(K)-B). The auto drain port comes with a ø3/8" One-touch fitting (applicable to the AWG30(K)-B to AWG40(K)-B).
\*4 Drain guide is G1/8 (applicable to the AWG20(K)-B) and G1/4 (applicable to the AWG30(K)-B to AWG40(K)-B).
\*5 Options B and H are not assembled and supplied loose at the time of shipment.
\*6 Assembly of a bracket and set nuts
\*7 When preserve is part optical effective which deve up to the average of the average

- \*7 When pressure is not applied, condensate which does not start the auto drain ending operations for the day is recommended.
- \*8 If the compressor is small (0.75 kW, discharge flow is less than 100 L/min (ANR)), air leakage from the drain cock may occur during the start of operations. N.C. type is recommended.
- \*10 Refer to chemical data on page 41 for chemical resistance of the bowl.
- \*11 A bowl guard is provided as standard equipment (polycarbonate).
   \*12 A bowl guard is provided as standard equipment (nylon).
- \*13 The combination of float type auto drain C and D is not available.
  \*14 Without a valve function
- \*14 Without a value function
  \*15 The combination of metal bowl 2 and 8 is not available.
  \*16 For pipe thread type: NPT. This product is for overseas use only according to the new Measurement Act. (The SI unit type is provided for use in Japan.)
  \*17 O: For pipe thread type: NPT only



# **AWG Series** Specific Product Precautions

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

### **Design/Selection**

# **M**Warning

- 1. Residual pressure disposal (outlet pressure removal) is not possible for the AWG20-B to AWG40-B even though the inlet pressure is exhausted. When the residual pressure disposal is performed, use the filter regulator with backflow function (AWG20K-B to AWG40K-B).
- 2. The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

			Material			
Туре	Chemical name	Application examples	Polycarbonate	Nylon		
Acid	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×		
Alkaline	Sodium hydroxide (Caustic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0		
Inorganic salts	Sodium sulfide Potassium nitrate Sulfate of soda	—	×	Δ		
Chlorine solvents	Carbon tetrachloride Chloroform Ethylene chloride Methylene chloride	Cleansing liquid for metals Printing ink Dilution	×	Δ		
Aromatic series	Benzene Toluene Paint thinner	Coatings Dry cleaning	×	Δ		
Ketone	Acetone Methyl ethyl ketone Cyclohexane	Photographic film Dry cleaning Textile industries	×	×		
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×		
Oil	Gasoline Kerosene	—	×	0		
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0		
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0		
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×		
Others	Thread-lock fluid Seawater Leak tester	_	×	Δ		
O: Esse	ntially safe	effects may occur. $\times$ :	Effects will	occur.		

When the above factors are present, or there is some doubt, use a metal bowl for safety.

### Maintenance

# **Warning**

1. Replace the element every 2 years or when the pressure drop becomes 0.1 MPa, whichever comes first, to prevent damage to the element.

### Mounting/Adjustment

# **M** Warning

- 1. Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- 2. Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

# **A** Caution

- Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
  - Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
  - Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).
- 2. When the bowl is installed on the AWG30(K)-B to AWG40(K)-B, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.



**S**SN



# A G Series Precautions

Be sure to read this before handling products. Refer to the back cover for safety instructions. For F.R.L. units precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

### Procedure for replacing or changing the mounting angle of a pressure gauge

## \land Warning

When replacing a pressure gauge and/or changing the mounting angle, release the inlet and outlet pressure completely. It is dangerous to replace the pressure gauge or change the mounting angle while it is under pressure.


### 1. Advance preparation

Keep the knob unlocked and completely loosened. The unlocked state of the knob can be visually confirmed by the "Orange mark" shown near the bottom of the knob.



### 2. Removing the knob


To remove the knob, align the  $\checkmark$  mark on the knob and the  $\blacktriangle$  mark on the bonnet and then pull the knob.



### 3. Removing the clip

When the  $\blacktriangle$  mark on the bonnet and the  $\blacktriangledown$  mark on the pressure regulator guide are aligned, the clip can be seen from the side window of the bonnet. The clip can be picked and removed with tweezers.


\* When adjusting the mark, turn the pressure regulator guide clockwise for adjustment.



### 4. Removing the pressure gauge

Pull the pressure gauge out by holding the outer edge of the dial.


\* Do not touch the internal mechanical portion (shown inside the dotted box). Accuracy of the pressure gauge may be adversely affected.



### 5. Setting the pressure gauge

After the mounting angle is adjusted as required, hold the outer edge of the pressure gauge dial and gently press down. For reference, the required clearance between the bottom of the dial and the top of the pressure regulator guide is shown in table 1.

- \* When the pressure gauge cannot be easily positioned, slightly rotate it. (The cog from the planet gear of the pressure regulator guide may be caught vertically in the cog from the sun gear which is mounted and integrated with the pressure gauge)
- Position the pressure gauge to the very bottom.
- \* Attached to the tip of the pressure gauge is an Oring with grease applied to it. Please use caution to prevent particles and/or dust from entering the pressure gauge when it is set. Otherwise, they may cause air leakage. Table 1




ble 1 Clearance

	Dimensions										
	ARG20-B AWG20-B										
X dimension (reference value)	2.6 mm	3.3 mm	3.3 mm								

### 6. Setting the clip

Insert the clip in the side of the bonnet when the  $\checkmark$  mark on the pressure regulator guide and the  $\blacktriangle$  mark on the bonnet are aligned. When inserting and setting the clip, use an instrument with a narrow tip, such as tweezers.

- \* The clip is slightly tapered toward its tip to prevent it from being released. Set the clip by slightly opening its tip.
- \* When the clip cannot easily be set, the cause may be as follows:
  - (1) The pressure regulator screw might have been in a lower position than the current one. (The pressure regulator screw may reach a lower position if the pressing force of the pressure regulator screw is excessively applied. This occurs because there is a clearance between the pressure regulator nut and pressure spring, when the pressure regulator screw is loosened completely.)
    - Countermeasures ..... Turn the pressure regulator guide approx. 5 times clockwise (pressure rise direction).
- (2) The pressure gauge is not firmly set. Countermeasures ····· Refer to 5 "Setting the pressure gauge."



7. Setting the knob Finished when the knob is set.

### ▲ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "**Caution**," "**Warning**" or "**Danger**." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)<sup>\*1</sup>, and other safety regulations.

- Caution: indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.
- Warning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

**Danger** indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

### **A**Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

- 2. Only personnel with appropriate training should operate machinery and equipment.
  - The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.
- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
  - The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

# 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.

- 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
- 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
- An application which could have negative effects on people, property, or animals requiring special safety analysis.
- 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

- \*1) ISO 4414: Pneumatic fluid power General rules relating to systems.
  - ISO 4413: Hydraulic fluid power General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)
  - ISO 10218-1: Manipulating industrial robots Safety. etc.

### 

 The product is provided for use in manufacturing industries. The product herein described is basically provided for peaceful use in manufacturing industries. If considering using the product in other industries, consult SMC beforehand

and exchange specifications or a contract if necessary. If anything is unclear, contact your nearest sales branch.

### Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

### Limited warranty and Disclaimer

- The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.\*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
  - \*2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

### **Compliance Requirements**

- The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

### 

### SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

A Safety Instructions Be sure to read the "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" before use.